



*ER-650/650R*

# Operation and Program Manual



All specifications are subject to change without notice

#### ATTENTION

The product that you have purchased contains a rechargeable Ni-MH battery. This battery is recyclable. At the end of its useful life, under various state and local laws, it may be illegal to dispose of the battery into the municipal waste system.

Check with your local solid waste officials for details concerning recycling options or proper disposal.



#### WARNING

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

## Precaution Statements

Follow these safety, servicing and ESD precautions to prevent damage and to protect against potential hazards such as electrical shock.

### 1-1 Safety Precautions

1. Be sure that all built-in protective devices are replaced. Restore any missing protective shields.
2. When reinstalling the chassis and its assemblies, be sure to restore all protective devices, including nonmetallic control knobs and compartment covers.
3. Make sure there are no cabinet openings through which people - particularly children - might insert fingers and contact dangerous voltages. Such openings include excessively wide cabinet ventilation slots and improperly fitted covers and drawers.
4. Design Alteration Warning:  
Never alter or add to the mechanical or electrical design of the SECR. Unauthorized alterations might create a safety hazard. Also, any design changes or additions will void the manufacturer's warranty.
5. Components, parts and wiring that appear to have overheated or that are otherwise damaged should be replaced with parts that meet the original specifications. Always determine the cause of damage or over-heating, and correct any potential hazards.
6. Observe the original lead dress, especially near the following areas : sharp edges, and especially the AC and high voltage supplies. Always inspect for pinched, out-of-place, or frayed wiring. Do not change the spacing between components and the printed circuit board. Check the AC power cord for damage. Make sure that leads and components do not touch thermally hot parts.
7. Product Safety Notice:  
Some electrical and mechanical parts have special safety-related characteristics which might not be obvious from visual inspection. These safety features and the protection they give might be lost if the replacement component differs from the original - even if the replacement is rated for higher voltage, wattage, etc.  
Components that are critical for safety are indicated in the circuit diagram by shading, () or (). Use replacement components that have the same ratings, especially for flame resistance and dielectric strength specifications. A replacement part that does not have the same safety characteristics as the original might create shock, fire or other hazards.

#### CAUTION

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the manufacturer.

Dispose used batteries according to the manufacturer's instructions.

#### ATTENTION

Il y a danger d'explosion s'il y a un remplacement incorrect de la batterie.

Remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur.

Mettre au rebut les batteries usagées conformément aux instructions du fabricant.



## 1-2 Servicing Precautions

**WARNING:** First read the-Safety Precautions-section of this manual. If some unforeseen circumstance creates a conflict between the servicing and safety precautions, always follow the safety precautions.

**WARNING:** An electrolytic capacitor installed with the wrong polarity might explode.

1. Servicing precautions are printed on the cabinet. Follow them.
2. Always unplug the units AC power cord from the AC power source before attempting to:
  - (a) Remove or reinstall any component or assembly
  - (b) Disconnect an electrical plug or connector
  - (c) Connect a test component in parallel with an electrolytic capacitor
3. Some components are raised above the printed circuit board for safety. An insulation tube or tape is sometimes used. The internal wiring is sometimes clamped to prevent contact with thermally hot components. Reinstall all such elements to their original position.
4. After servicing, always check that the screws, components and wiring have been correctly reinstalled. Make sure that the portion around the serviced part has not been damaged.
5. Check the insulation between the blades of the AC plug and accessible conductive parts (examples : metal panels and input terminals).
6. Insulation Checking Procedure:

Disconnect the power cord from the AC source and turn the power switch ON. Connect an insulation resistance meter (500V) to the blades of AC plug.

The insulation resistance between each blade of the AC plug and accessible conductive parts (see above) should be greater than 1 megohm.
7. Never defeat any of the B+ voltage interlocks. Do not apply AC power to the unit (or any of its assemblies) unless all solid-state heat sinks are correctly installed.
8. Always connect an instrument's ground lead to the instrument chassis ground before connecting the positive lead ; always remove the instrument's ground lead last.

## 1-3 Precautions for Electrostatically Sensitive Devices (ESDs)

1. Some semiconductor (solid state) devices are easily damaged by static electricity. Such components are called Electrostatically Sensitive Devices (ESDs); examples include integrated circuits and some field-effect transistors. The following techniques will reduce the occurrence of component damage caused by static electricity.
2. Immediately before handling any semiconductor components or assemblies, drain the electrostatic charge from your body by touching a known earth ground. Alternatively, wear a discharging wrist-strap device. (Be sure to remove it prior to applying power - this is an electric shock precaution.)
3. After removing an ESD-equipped assembly, place it on a conductive surface such as aluminum foil to prevent accumulation of electrostatic charge.
4. Do not use freon-propelled chemicals. These can generate electrical charges that damage ESDs.
5. Use only a grounded-tip soldering iron when soldering or unsoldering ESDs.
6. Use only an anti-static solder removal device. Many solder removal devices are not rated as anti-static; these can accumulate sufficient electrical charge to damage ESDs.
7. Do not remove a replacement ESD from its protective package until you are ready to install it. Most replacement ESDs are packaged with leads that are electrically shorted together by conductive foam, aluminum foil or other conductive materials.
8. Immediately before removing the protective material from the leads of a replacement ESD, touch the protective material to the chassis or circuit assembly into which the device will be installed.
9. Minimize body motions when handling unpackaged replacement ESDs. Motions such as brushing clothes together, or lifting a foot from a carpeted floor can generate enough static electricity to damage an ESD.



# Contents

|   |           |
|---|-----------|
| <b>Getting Started</b>                                | <b>1</b>  |
| About the <i>ER-650/650R</i> .....                    | 1         |
| Using this Manual.....                                | 2         |
| Unpacking.....  | 2         |
| Installing the Paper.....                             | 3         |
| Basic Features and Functions.....                     | 6         |
| Standard Hardware.....                                | 6         |
| Optional Hardware.....                                | 6         |
| Software Features.....                                | 6         |
| ER-650 Default Keyboard.....                          | 8         |
| ER-650 Program Overlay.....                           | 8         |
| ER-650R Default Keyboard.....                         | 9         |
| ER-650R Program Overlay.....                          | 9         |
| Programmable Function Keys.....                       | 10        |
| Control Lock.....                                     | 14        |
| Front Display.....                                    | 15        |
| Rear Display.....                                     | 18        |
| Initial Clear.....                                    | 19        |
| <br>  |           |
| <b>Operating Instructions</b>                         | <b>21</b> |
| Operator Display Screen.....                          | 21        |
| Operator Display Example.....                         | 22        |
| Clerk Operations.....                                 | 23        |
| Clerk Sign On Instructions.....                       | 24        |
| Clerk Sign Off Instructions.....                      | 24        |
| Clerk Time Keeping.....                               | 25        |
| Item Registrations.....                               | 27        |
| Open Keyboard PLU Entry.....                          | 28        |
| Preset Price Keyboard PLU.....                        | 28        |
| Keyboard PLU Repeat Entry.....                        | 29        |
| Keyboard PLU Multiplication.....                      | 30        |
| Keyboard PLU Multiplication with Decimal Point.....   | 31        |
| Split Pricing (Keyboard PLU).....                     | 32        |
| Single Item Keyboard PLU.....                         | 33        |
| Open Code Entry PLU.....                              | 34        |
| Preset Price Code Entry PLU.....                      | 34        |
| Code Entry PLU Multiplication.....                    | 35        |
| Code Entry PLU Multiplication with Decimal Point..... | 36        |
| Split Pricing Code Entry PLU.....                     | 36        |
| PLU Price Inquiry.....                                | 37        |
| Modifier Key.....                                     | 38        |
| Price Level Key.....                                  | 39        |
| Promo.....  | 40        |

|   |    |
|---|----|
| Waste .....                                 | 41 |
| Shifting or Exempting Tax .....             | 42 |
| Shifting Tax .....                          | 42 |
| Exempting Tax .....                         | 43 |
| Percent Key Operations .....                | 45 |
| Preset Percent Discount on an Item .....    | 45 |
| Enter a Percent Discount on an Item .....   | 46 |
| Percent on Sale Total .....                 | 46 |
| Coupon on Sale (Vendor Coupon) .....        | 47 |
| Coupon on Item (Store Coupon) .....         | 48 |
| Return Merchandise Registrations .....      | 49 |
| Voids and Corrections .....                 | 50 |
| Error Correction (Void Last Item) .....     | 50 |
| Void Previous Item .....                    | 50 |
| Cancel .....                                | 51 |
| Void Position Operations .....              | 51 |
| No Sale Operations .....                    | 52 |
| Open Drawer .....                           | 52 |
| Non Add Number .....                        | 52 |
| Received On Account Operations .....        | 53 |
| Paid Out Operations .....                   | 54 |
| Subtotaling a Sale .....                    | 55 |
| Eat In/Take Out/Drive Thru Sales .....      | 55 |
| Totaling and Tendering .....                | 56 |
| Totaling a Cash Sale .....                  | 56 |
| Totaling a Check Sale .....                 | 56 |
| Tendering a Cash Sale .....                 | 57 |
| Tendering a Check Sale .....                | 57 |
| Totaling a Charge Sale .....                | 58 |
| Tendering a Charge Sale .....               | 59 |
| Check Cashing .....                         | 60 |
| Split Tender .....                          | 61 |
| Post Tender .....                           | 62 |
| Food Stamp Sales .....                      | 63 |
| Currency Conversion .....                   | 64 |
| Receipt On/Off and Receipt on Request ..... | 65 |
| Check Tracking Operations .....             | 66 |
| Overview .....                              | 66 |
| Posting Balances Manually .....             | 68 |
| Soft Check .....                            | 70 |
| Hard Check .....                            | 73 |
| Fast Food Drive Thru .....                  | 76 |
| Scale Operations .....                      | 78 |
| Direct Scale Entry .....                    | 79 |
| Automatic Scale Entry .....                 | 80 |
| Tare Weight Entry .....                     | 80 |
| Manual Tare Weight Entry .....              | 81 |
| Manual Weight Entry .....                   | 82 |

## X Mode

**83**

|                         |    |
|-------------------------|----|
| Manager Mode .....      | 83 |
| Manager Operation ..... | 84 |
| X Reports .....         | 85 |
| Declaration .....       | 87 |



|                             |    |
|-----------------------------|----|
| Register Print Format.....  | 88 |
| Stop Register Printing..... | 89 |
| Training Mode.....          | 90 |
| E.J. Operation.....         | 91 |

**Z Mode 93**

|                               |     |
|-------------------------------|-----|
| Reset Report Mode.....        | 93  |
| Z Reports.....                | 94  |
| Reset Electronic Journal..... | 96  |
| PC Communication.....         | 96  |
| PLU Lookup Program.....       | 97  |
| Age Verification.....         | 99  |
| KP Starting No.....           | 100 |

**Service Mode Programming 101**

|   |     |
|---|-----|
| Overview.....                             | 101 |
| Clearing Memory.....                      | 103 |
| Memory All Clear.....                     | 103 |
| Hardware Test.....                        | 105 |
| Hardware Test Table.....                  | 105 |
| Clear All Totals.....                     | 106 |
| Clear Grand Total.....                    | 106 |
| Clear PLU File.....                       | 107 |
| EPROM Information.....                    | 107 |
| Memory Allocation.....                    | 108 |
| Function Key Assignment.....              | 110 |
| Function Key Codes.....                   | 112 |
| IRC Options.....                          | 113 |
| RS232C Port 1/RS232C Port 2 Options.....  | 114 |
| RS232C Settings Screen Program Notes..... | 117 |

**Program Mode Programming 119**

|  |     |
|--|-----|
| Descriptor Programming Methods.....            | 119 |
| Program Overlay Method.....                    | 119 |
| Descriptor Code Method.....                    | 120 |
| Program Mode Menu.....                         | 121 |
| PLU Programming.....                           | 123 |
| Add/Modify PLU.....                            | 123 |
| PLU Options - Reference Information.....       | 126 |
| Delete PLU.....                                | 128 |
| Group Programming.....                         | 131 |
| Sales Tax Programming.....                     | 134 |
| Programming an Add-On Tax Rate Percentage..... | 135 |
| Programming a Tax Table.....                   | 136 |
| Programming a VAT (Value Added Tax).....       | 140 |
| Programming a Canadian GST.....                | 141 |
| System Option Programming.....                 | 142 |
| System Options - Reference Information.....    | 146 |
| Print Option Programming.....                  | 150 |
| Clerk Programming.....                         | 158 |
| Clerk Programming - Reference Information..... | 159 |
| Function Key Programming.....                  | 160 |
| #/NS.....                                      | 161 |

|                                 |     |
|---------------------------------|-----|
| % 1 -%5 .....                   | 163 |
| ADD CHECK.....                  | 166 |
| CANCEL.....                     | 168 |
| CASH.....                       | 169 |
| CHARGE 1-8.....                 | 171 |
| CHECK CASHING.....              | 173 |
| CHECK ENDORSEMENT.....          | 174 |
| CHECK.....                      | 176 |
| CHECK #.....                    | 178 |
| CURRENCY CONVERSION 1-4.....    | 180 |
| EAT-IN TAKE OUT DRIVE THRU..... | 181 |
| ERROR CORRECT.....              | 182 |
| F/S TEND.....                   | 183 |
| FUNCTION LOOK UP (1-2).....     | 185 |
| GUEST.....                      | 187 |
| LEVEL 1-5.....                  | 188 |
| MDSE RETURN.....                | 189 |
| MODIFIER 1-5.....               | 190 |
| PBAL.....                       | 192 |
| PAID OUT 1-3.....               | 193 |
| PRINT CHECK.....                | 194 |
| PROMO.....                      | 195 |
| RECD ON ACCT 1-3.....           | 196 |
| SCALE.....                      | 197 |
| SERVICE.....                    | 199 |
| TABLE.....                      | 201 |
| TARE.....                       | 202 |
| TAX EXEMPT.....                 | 203 |
| TIME IN/OUT.....                | 204 |
| TIP.....                        | 205 |
| VALIDATE.....                   | 207 |
| VOID ITEM.....                  | 208 |
| WASTE.....                      | 209 |
| Logo Descriptor.....            | 210 |
| Preamble.....                   | 211 |
| Postamble.....                  | 212 |
| Endorsement Message.....        | 213 |
| Financial Report.....           | 214 |
| Clerk Report.....               | 215 |
| Macro Name.....                 | 216 |
| NLU Code Number.....            | 217 |
| Download Programs.....          | 218 |
| Clerk In/Out.....               | 220 |
| PLU Stock.....                  | 221 |
| Drawer Limit.....               | 222 |
| Check Change Limit.....         | 223 |
| Time & Date.....                | 224 |
| Tare Weight.....                | 225 |
| Macro.....                      | 226 |
| Programming a New Macro.....    | 227 |
| Editing an Existing Macro.....  | 228 |
| Machine No. ....                | 229 |
| PC Schedule Time.....           | 230 |
| Training Mode Password.....     | 231 |
| Program Scans.....              | 232 |

|                              |                |
|------------------------------|----------------|
| <b>Sample Reports</b>        | <b>235</b>     |
| Financial .....              | 235            |
| Time .....                   | 239            |
| PLU.....                     | 240            |
| Clerk .....                  | 241            |
| Individual Clerk .....       | 242            |
| Groups .....                 | 243            |
| Stock .....                  | 244            |
| Clerk Time Report .....      | 245            |
| Check File.....              | 246            |
| PLU Zero Sale .....          | 247            |
| Balancing Formulas .....     | 248            |
| <br><b>Glossary of Terms</b> | <br><b>249</b> |
| <br><b>Index</b>             | <br><b>255</b> |

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)