




Samsung SER-6500/6540 Electronic Cash Register

Operator's and Programming Manual



SAMSUNG ELECTRONICS LTD.

TABLE OF CONTENTS

INSTALLATIONS.....	1
RIBBON CASSETTE INSTALLATION	1
RECEIPT/JOURNAL PAPER INSERTION	2
ALL CLEAR PROCEDURE	3
INITIAL CLEAR PROCEDURE	4
INSTALL DEFAULT KEYBOARD.....	4
S-POSITION REGISTER NUMBER PROGRAMMING	5
S-POSITION SERVICE FUNCTIONS	5
S-POSITION COMMUNICATION TEST	6
<i>Loop Back Test Connections</i>	6
PROGRAMMING.....	7
P-POSITION PROGRAMMING SCANS	7
S-MODE KEY RELOCATION PROGRAMMING.....	8
OPTION PROGRAMMING	9
<i>S-Mode Program Option</i>	10
<i>P-Mode Program Option</i>	12
<i>P-Mode Communication Option</i>	17
TAX PROGRAMMING	22
<i>Straight Tax Programming</i>	22
<i>Table Tax rate Programming</i>	23
FUNCTION KEY PROGRAMMING	25
<i>CASH Key Programming</i>	25
<i>CHECK Key Programming</i>	26
<i>CHARGE Key Programming</i>	27
<i>CURRENCY Key Programming</i>	28
<i>% Key Programming</i>	29
<i>ERR CORR Key Programming</i>	31
<i>VOID Key Programming</i>	32
<i>PROMO Key Programming</i>	33
<i>WASTE Key Programming</i>	34
<i>CANCEL Key Programming</i>	35
<i>Paid Out Key Programming</i>	36
<i>Received on Account Key Programming</i>	37
<i>RETURN Key Programming</i>	38
<i>TAX EXEMPT Key Programming</i>	39
<i>EAT-IN/TAKE-OUT/DRIVE-THROUGH Key Programming</i>	40
<i>PRINT Key Programming</i> ⁰⁰	41
<i>NO SALE Key Programming</i>	42
<i>VALIDATION ON SLIP PRINTERG Key Programming</i>	43
<i>TIME IN/OUT Key Programming</i>	44
<i>P/BAL Key Programming</i>	45
<i>CHECK # Key Programming</i>	46
<i>TABLE # Key Programming</i>	47
<i>GUEST # Key Programming</i>	48
<i>SERVICE Key Programming</i>	49
<i>PRINT CHECK / SLIP PRINT Key Programming</i>	50
<i>TIP Key Programming</i>	51
<i>ADD STOCK/DEDUCT STOCK/STOCK OVERWRITE Key Programming</i>	52
<i>STOCK ENQUIRY Key Programming</i>	53

<i>MACRO Key Programming</i>	54
PLU PROGRAMMING	55
<i>Direct PLU Programming (All Parts)</i>	57
<i>Direct PLU Deletion</i>	58
<i>Direct PLU Status Programming</i>	58
<i>Direct PLU PRICE/HALO Programming</i>	58
<i>Direct PLU Descriptor Programming</i>	58
<i>Direct PLU Link PLU Programming</i>	59
<i>Direct PLU Link Department Programming</i>	59
<i>Direct PLU Mix & Match Table Link Programming</i>	60
<i>Direct PLU Kitchen Printer Programming</i> ⁰⁰	60
<i>Batch PLU Programming (All Parts)</i>	61
<i>Batch PLU Deletion Programming</i>	62
<i>Clear Batch PLU</i>	62
<i>Run Batch PLU</i>	62
PLU STOCK TAKING PROGRAMMING	63
<i>Add Stock</i>	63
<i>Deduct Stock</i>	63
<i>Stock Overwrite</i>	63
<i>PLU Minimum Stock level Programming</i>	64
DEPARTMENT PROGRAMMING.....	65
<i>DEPARTMENT PROGRAMMING (All Parts)</i>	66
<i>Department Status Programming</i>	67
<i>Department Price/Halo Programming</i>	67
<i>Department Description Programming</i>	67
<i>Department Link Group Programming</i>	68
<i>Department Kitchen Printer Programming</i> ⁰⁰	68
NON PLU PROGRAMMING ⁴⁰	69
PLU PLACEMENT PROGRAMMING (NLU PROGRAMMING)	69
SET MENU PROGRAMMING	70
MIX & MATCH TABLE PROGRAMMING.....	71
CLERK PROGRAMMING	72
<i>Clerk Secret Code Programming</i>	72
<i>Clerk Description Programming</i>	72
<i>Clerk Status Programming</i>	72
<i>Clerk Labour Group Description Programming</i>	73
NORMAL GROUP PROGRAMMING	73
<i>Normal Group Description Programming</i>	73
<i>Normal Group Status Programming</i>	73
KITCHEN PRINTER ROUTE PROGRAMMING ⁰⁰	74
<i>Kitchen Printer Route Programming</i>	74
<i>Kitchen Printer Route Back-Up Programming</i>	74
<i>Kitchen Printer Description Programming</i>	74
FINANCIAL REPORT MESSAGE PROGRAMMING	75
DISPLAY / PRINT DESCRIPTION PROGRAMMING	75
ERROR MESSAGE PROGRAMMING	75
CLERK REPORT MESSAGE PROGRAMMING.....	76
LOGO MESSAGE PROGRAMMING	76
STRING REPORT PROGRAMMING.....	77
<i>STRING REPORT PROGRAMMING</i>	77
TIME SCHEDULE FOR STRING REPORT	78
MENU LEVEL SCHEDULE PROGRAMMING	78
DATE AND TIME PROGRAMMING.....	79

<i>Date and time programming</i>	79
<i>Date programming</i>	79
<i>Time programming</i>	79
OPERATIONS	80
INTRODUCTION.....	80
FUNCTION OF MODE CONTROLS	81
DEFAULT KEYBOARD LAYOUT.....	82
<i>Default keyboard layout for SER6500</i>	82
<i>Default keyboard layout for SER6540</i>	82
KEY DESCRIPTION	83
CLERK SIGN ON/OFF.....	87
<i>Push button clerk entry (default)</i>	87
<i>Clerk code entry</i>	87
<i>Real clerk key entry</i>	88
CLERK REGISTRATION MODE.....	89
<i>Stay down mode</i>	89
<i>Popup mode</i>	89
FLOATING CLERK SYSTEM.....	90
<i>When floating clerk operation is enabled</i>	90
<i>When floating clerk operation is disabled</i>	90
CLERK TIME IN/OUT	91
ENTERING STARTING CASH AMOUNT.....	92
<i>Addition</i>	92
<i>Subtraction</i>	92
ITEM SALE ENTRIES.....	93
<i>Single item entries</i>	93
<i>Repeat entries</i>	94
<i>Multiplication entries</i>	95
<i>Split pricing entries</i>	96
<i>Price change</i>	97
<i>Not found PLU</i>	98
<i>Price enquiry</i>	99
<i>Stock enquiry</i>	99
OTHER ENTRIES FOR PLU & DEPT.....	100
<i>Price shift</i>	100
<i>Level shift (only for direct PLU)</i>	101
<i>Link PLU entries</i>	102
<i>Set menu entries</i>	102
<i>Mix and match operation</i>	103
FINALISING OF TRANSACTION.....	104
<i>Cash or cheque tendering</i>	104
<i>Charge tendering</i>	104
<i>Tendering without tender amount entry</i>	104
<i>Mixed tendering</i>	105
TAX OPERATION.....	105
<i>Collecting tax</i>	105
<i>Exempting tax</i>	106
CORRECTIONS	108
<i>Error correct</i>	108
<i>Previous void with VOID key</i>	108
<i>All void</i>	109
PROMO & WASTE.....	109

<i>Promo</i>	109
<i>Waste</i>	110
OTHER ENTRIES	110
% entry.....	110
Non add # entry	113
REFUND FUNCTION	114
PAYMENT.....	115
<i>R/A (Received on account) entries</i>	115
<i>Paid out</i>	115
<i>Currency exchange</i>	116
<i>No sale</i>	116
CHECK OPERATION	117
<i>New check</i>	117
<i>Additional ordering</i>	117
<i>Bill Printing</i>	117
<i>Bill addition</i>	118
<i>Bill transfer</i>	118
<i>Negative Credit</i>	119
CLERK INTERRUPT OPERATION.....	120
TRAINING MODE.....	122
<i>Enter training mode</i>	122
<i>Exit training mode</i>	122
PRINTINGS.....	123
<i>Receipt on/off operation</i>	123
<i>Post receipt operation</i>	123
REPORTS	124
<i>Cash declaration</i>	124
<i>Report list</i>	125
CONSOLIDATING REPORTS.....	129
PROGRAM DOWNLOAD.....	130
HOW TO PROGRAM ALPHANUMERIC CHARACTERS	131
USING DIRECT CHARACTER KEY ON KEYBOARD.....	131
USING CHARACTER CODE	131
APPENDIX	132
SER 6500/40 CHARACTER CODE TABLE	132
SER 6500 KEY CHARACTER MAP.....	133
SER 6540 KEY CHARACTER MAP.....	133
DISPLAY PRINT DESCRIPTION DEFINITIONS	134
ERROR MESSAGE DEFINITIONS.....	136
SER-6500/40 PGM COMMAND.....	139

Important Notations

⁰⁰ : SER6500 only.

⁴⁰ : SER6540 only.

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)