

Sanyo ECR-160 operation and programming Manual

Electronic Cash Register

ECR 160

Instruction Manual



 **SANYO**

ATTENTION

For your protection in the event of theft or loss of this product, please fill in the information requested below.

Model No _____

Serial No _____

(Located on the right side of the unit)

Date of Purchase _____

Purchase Price _____

Where Purchased _____

This SANYO electronic cash register uses the keyboard presetting system.

This enables its universal use whether or not tax is required or different tax rates.

At the time of purchase, it is necessary to initialize the machine according to the installation procedures to clear the memory and preset the required data.

The details of the procedures are explained in a later section.

It is recommended that these procedures are followed carefully.

Contents

Features	1
Name of Components	2
Keyboard	3
Keys on the Keyboard	4
Indicator	6
Print Symbols	6
Printer Operation	7
Clearing the Memory	9
DATE & Time Setting	9
How to Program	9
Registration Examples	14
Special Registration Examples	18
How to obtain the Read Total & the Reset Total	20
Drawer	21
Alarm buzzer	22
Suggestions for Using the Machine	23
Recommended Practices	23
Guarantee	23
Specification	24

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Sanyo/ECR-160 operation and programming ma](https://the-checkout-tech.com/manuals/Sanyo/ECR-160%20operation%20and%20programming%20manual.pdf)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)