

SANYO

Electronic Cash Register

071119AW

ECR 225/230/235



Instruction Manual

TABLE OF CONTENTS

Introduction	I
Chapter 1 General Descriptions	1
1. Appearance and nomenclature	2
2. Specification	2
3. Setting Up your Register	2
Initial Program Loading	2
Auto-loading Keyboard	4
Customizing Keyboard	4
Initialization of Grand totals and Z counters	4
4. Display	5
5. Mode Lock and Control Keys	5
6. Keyboard and Functional Keys	6
ECR225/ECR235 Keyboard Layout	6
Key Name and Function for ECR225 and ECR235	7
7. Drawer	8
8. Printer	9
Chapter 2 Operating Method	11
9. Opening the store	11
10. Basic Transaction Sequence	11
11. Error Warning	11
12. Receipt Sample	12
13. Department Entry	12
Department Entries	12
Multiplication Entries	12
Repeat Entries	12
Split Pricing Entries	13
Square Calculation Entries (Program option)	13
Single-Item Entries (Program option)	13
14. Price Look Up (PLU) Entry	13
15. Tax	14
Taxable Department Entries	14
Tax Modifier (SHIFT1,SHIFT 2, SHIFT3)	14
Tax Exemption	14
16. Subtotal	14
17. Tendering Operation	15
Cash Sale	15
Cheque Sale	15
Charge Sale	15
Split Tendering	16
Cheque Cashing	16
18. Error Correction	16
Clear Key	16
Void Key	16
19. Refund Operation	17
General Refund	17
Single Refund	17
Department Refund	17
20. Discount Operation	18
Item % Discount (Mark down)	18
% Discount on the Transaction Total	18
Amount Discount on the Transaction Total	18

21. No Sale Operation	18
22. Mark-up Operation	19
23. Non-add Print Operation	19
24. Paid Out Operation	19
25. Received-on-Account Operation	19
26. Credit Card Operation	20
27. Currency Conversion Operation	20
28. Showing Current Time	21
29. Delayed Receipt (Program option)	21
30. Power Failure	21
31. Closing the Store	21
Chapter 3 Reading and Resetting Sales Reports	22
32. Cash in Drawer Declaration	22
33. General Report	23
34. PLU Report	25
35. Nonresettable GT Report	25
36. Hourly Daily Total Report	25
Chapter 4 Programming Your Register	26
37. Date and Time Setting	26
38. Receipt Number Setting	27
39. ID Code and Machine Number Setting	27
40. Percent Rate Setting for % KEY	27
41. Machine Size Setting	28
42. Print Line Elimination	29
43. System Programming	30
44. Department Programming	31
45. PLU Programming	32
46. Tendering Keys Programming	32
47. Function Keys Programming	33
48. Refund, PO/REF Key Programming	33
49. Cheque Cashing limit	33
50. Currency Conversion Programming	34
51. Tax Programming	35
No Tax Mode	35
Straight % Tax	35
VAT (Value Added Tax)	35
Tax Table Look-up with Percent Add-on	36
Tax Table Look-up	37
Chapter 5 Program Confirmation	38
52. Confirmation of Program	38
53. Self Diagnostics	39
Chapter 6 Appendix	40
Key Code Table	40
Error Code Messages	41
Other Problems	42

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Sanyo/ECR-225 and ECR-230 and ECR-235 op](https://the-checkout-tech.com/manuals/Sanyo/ECR-225%20and%20ECR-230%20and%20ECR-235%20op.pdf)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)