

SHARP SERVICE MANUAL

CODE : 00ZER1017SM-E



ELECTRONIC CASH REGISTER

MODEL ER-1017

Printer: MP-828CR

CONTENTS

1. Function Summary	1
2. Specifications	1
3. Memory	4
4. Initial Resetting/Date setting	4
5. %, Rate Setting, Reading	4
6. Option (Backup Memory/Operation Battery: ER-17BT)	5
7. Circuit Block Diagram	6
8. CPU (SC38800B63) Terminal Signals	7
9. Circuit Diagram	8
10. P.W.B. Layout	10
11. Parts List & Guide	

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-1017 service manual.html](https://the-checkout-tech.com/manuals/sharp/ER-1017%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)