

# SHARP

# SERVICE MANUAL



## MODEL ER-1772

### ELECTRONIC CASH REGISTER

( PRINTER: MODEL-355 )  
( MODE KEY NO.: GZ25 )

#### CONTENTS

|  |    |
|--|----|
| 1. REFERENCE DOCUMENTS .....                       | 2  |
| 2. OUTLINE OF FUNCTIONS .....                      | 2  |
| 3. SPECIFICATIONS .....                            | 3  |
| 3-1. Rating .....                                  | 3  |
| 3-2. Keyboard .....                                | 3  |
| 3-3. Display .....                                 | 4  |
| 3-4. Printer .....                                 | 5  |
| 3-5. Print Formats .....                           | 7  |
| 3-6. Error Processing .....                        | 9  |
| 3-7. Drawer/Lock .....                             | 9  |
| 3-8. Protection From Power Failure .....           | 10 |
| 3-9. Memories .....                                | 11 |
| 4. OPTIONS .....                                   | 11 |
| 5. SERVICE (SRV) MODE .....                        | 12 |
| 5-1. Program Reset .....                           | 12 |
| 5-2. Master Reset* (All memories clear) .....      | 12 |
| 5-3. Setting Item (SRV1 mode) .....                | 12 |
| 5-4. Preset Reading (SRV1 mode) .....              | 14 |
| 6. PROGRAM (PGM) MODE .....                        | 14 |
| 6-1. Preset .....                                  | 14 |
| 6-2. Preset Reading .....                          | 15 |
| 7. DATE MODE .....                                 | 16 |
| 8. READING, RESETTING .....                        | 16 |
| 8-1. Reading (X mode) .....                        | 16 |
| 8-2. Resetting (Z mode) .....                      | 16 |
| 9. CAUTIONS ON SERVICING .....                     | 17 |
| 10. CIRCUIT BLOCK DIAGRAM .....                    | 18 |
| 11. CIRCUIT DESCRIPTIONS .....                     | 19 |
| 11-1. LI3073 Terminal Signal .....                 | 19 |
| 11-2. Keyboard Control .....                       | 19 |
| 11-3. Display Control .....                        | 19 |
| 11-4. RAM Control (256 x 4 bits) .....             | 20 |
| 11-5. Printer Control (M-355) .....                | 20 |
| 11-6. Printer Power Supply and Brake Circuit ..... | 20 |
| 11-7. Power Supply Circuit .....                   | 20 |
| 11-8. ACL Signal .....                             | 20 |
| 11-9. Drawer Control .....                         | 21 |
| 12. FITTING PROCEDURE OF REAR DISPLAY TUBE .....   | 22 |
| 13. DEPARTMENT EXPANSION (2 to 4 DEPT.) .....      | 22 |
| 14. CHANGE OF NUMERIC KEY TOPS FOR U.K. ONLY ..... | 23 |
| 15. CIRCUIT DIAGRAM AND PWB LAYOUT .....           | 23 |
| 16. PARTS GUIDE .....                              |    |

SHARP CORPORATION

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-1772 service manual.html](https://the-checkout-tech.com/manuals/sharp/ER-1772%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)