


SHARP SERVICE MANUAL

CODE : 00ZER1772SSME



ELECTRONIC CASH REGISTER

MODEL **ER-1772S**

PRINTER: MODEL-365E

SRV KEY Part code: LKGiM6861RCZZ

CONTENTS

1. REFERENCE DOCUMENTS	1
2. OUTLINE OF FUNCTIONS	1
3. SPECIFICATIONS	1
3-1. Rating	1
3-2. Keyboard	2
3-3. Display	2
3-4. Printer	3
3-5. Error Processing	3
3-6. Drawer/Lock	3
3-7. Protection From Power Failure	4
3-8. Memories	4
4. OPTIONS	5
5. SERVICE (SRV) MODE	5
5-1. Program Reset	5
5-2. Master Reset* (All memories clear)	5
5-3. Setting Item (SRV1 mode)	5
5-4. Preset Reading (SRV1 mode)	6
6. PROGRAM (PGM) MODE	6
6-1. Preset	6
6-2. Preset Reading	7
7. DATE MODE	7
8. READING, RESETTING	7
8-1. Reading (X mode)	7
8-2. Resetting (Z mode)	7
9. CAUTIONS ON SERVICING	8
10. CIRCUIT BLOCK DIAGRAM	8
11. CIRCUIT DESCRIPTIONS	9
11-1. LI3073 Terminal Signals	9
11-2. Keyboard Control	9
11-3. Display Control	9
11-4. RAM Control (256 x 4 bits)	9
11-5. Printer Control (M365E)	9
11-6. Motor Drive and Brake Circuit	10
11-7. Power Supply Circuit	10
11-8. Battery Circuit	10
11-9. Drawer Control	11
12. DEPARTMENT EXPANSION (2 to 4 DEPT.)	11
13. MODIFICATION FOR CLOCK FUNCTION	11
14. CIRCUIT DIAGRAM AND PWB LAYOUT	12
15. PARTS GUIDE	

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)