

SHARP SERVICE MANUAL



MODEL ER-1871

ELECTRONIC CASH REGISTER

CONTENTS

1. SPECIFICATIONS	1	4-4 AUTO CLEAR SIGNAL	12
1-1 GENERAL	2	4-5 IR2402	13
1-2 KEY	2	5. METHOD OF SRV. KEY	14
1-3 DISPLAY	2	6. OPERATION MAP	15
1-4 PRINT	3	7. POWER SUPPLY CIRCUIT DIAGRAM AND LAYOUT	16
1-5 MEMORIES	4	8. MAIN AND KEY PWB CIRCUIT DIAGRAM	17
1-6 MECHANISM	5	9. MAIN PWB LAYOUT	18
1-7 DRAWER	5	10. KEY PWB LAYOUT	19
2. OPERATION	6	PARTS LIST & GUIDE	20
2-1 PRINT FORMAT	6		
2-2 PRINT OUT EXAMPLES	6		
2-3 RESET TABLE	7		
2-4 ERRORS	7		
2-5 POWER FAILURE AND CONSEQUENCE	7		
3. BLOCK DIAGRAM	8		
4. LOGIC	9		
4-1 INPUT/OUTPUT OF LSI	9		
4-2 KEY AND DISPLAY ACTIONS OF LSI	10		
4-3 PRINTING ACTION OF LSI	11		

Note 1 As to the service document of the printer employed for this machine, refer to the SE-61 PRINTER SERVICE MANUAL.

Note 2 SRV. key is required to repair this model.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-1871 service manual.html](https://the-checkout-tech.com/manuals/sharp/ER-1871%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)