

# SHARP SERVICE MANUAL



## MODEL ER-1871

### ELECTRONIC CASH REGISTER

#### CONTENTS

1. SPECIFICATIONS .....	1	4-4 AUTO CLEAR SIGNAL .....	12
1-1 GENERAL .....	2	4-5 IR2402 .....	13
1-2 KEY .....	2	5. METHOD OF SRV. KEY .....	14
1-3 DISPLAY .....	2	6. OPERATION MAP .....	15
1-4 PRINT .....	3	7. POWER SUPPLY CIRCUIT DIAGRAM AND LAYOUT .....	16
1-5 MEMORIES .....	4	8. MAIN AND KEY PWB CIRCUIT DIAGRAM .....	17
1-6 MECHANISM .....	5	9. MAIN PWB LAYOUT .....	18
1-7 DRAWER .....	5	10. KEY PWB LAYOUT .....	19
2. OPERATION .....	6	PARTS LIST & GUIDE .....	20
2-1 PRINT FORMAT .....	6		
2-2 PRINT OUT EXAMPLES .....	6		
2-3 RESET TABLE .....	7		
2-4 ERRORS .....	7		
2-5 POWER FAILURE AND CONSEQUENCE .....	7		
3. BLOCK DIAGRAM .....	8		
4. LOGIC .....	9		
4-1 INPUT/OUTPUT OF LSI .....	9		
4-2 KEY AND DISPLAY ACTIONS OF LSI .....	10		
4-3 PRINTING ACTION OF LSI .....	11		

Note 1 As to the service document of the printer employed for this machine, refer to the SE-61 PRINTER SERVICE MANUAL.

Note 2 SRV. key is required to repair this model.

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)