


# SHARP

# SERVICE MANUAL



## MODEL ER-1873

### ELECTRONIC CASH REGISTER

Printer : SE-6304  
Service Key Code : LKGiM1004CCZZ  
(No mode key No.)

### CONTENTS

1. REFERENS DOCUMENTS .....	1
2. OPTIONS .....	2
3. OUTLINE OF FUNCTIONS .....	3
4. SPECIFICATIONS .....	3
5. SERVICE (SRV) MODE .....	12
6. PROGRAM (PGM) MODE .....	19
7. DATE MODE .....	21
8. READING (X) & RESETING (Z) MODE .....	21
9. PRECAUTIONS ON SERVICING .....	22
10. CIRCUIT BLOCK DIAGRAM – 1 .....	25
11. CIRCUIT BLOCK DIAGRAM – 2 .....	26
12. $\mu$ PD766-115 TERMINAL SIGNALS .....	28
13. $\mu$ PD7507-015 TERMINAL SIGNALS .....	30
14. EXPANSION OF DEPARTMENT .....	32
15. CIRCUIT DIAGRAMS AND P.W.B. LAYOUT	
16. PARTS GUIDE	

SHARP CORPORATION

DOCUMENT CODE : 00ZER1873SM-1

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-1873 service manual.html](https://the-checkout-tech.com/manuals/sharp/ER-1873%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)