

SHARP SERVICE MANUAL

CODE: 00ZER1875SM-E

ELECTRONIC CASH REGISTER

PRINTER: CR-802 2-10

SERVICE KEY CODE: LKGIM6861RCZZ



MODEL **ER-1875**

CONTENTS

1. INTERNAL BLOCK DIAGRAM	1
2. REFERENCE DOCUMENT	2
3. OPTIONS	2
4. SPECIFICATIONS	2
5. OUTLINE OF FUNCTIONS	7
6. SERVICE (SRV) MODE	8
7. PROGRAM (PGM) MODE	11
8. DATE MODE	12
9. READING (X) & RESETTING (Z) MODE	13
10. SERVICE PRECAUTIONS	14
11. CIRCUIT BLOCK DIAGRAM	15
12. CIRCUIT DESCRIPTIONS	16
13. LI3078 TERMINAL SIGNAL	19
14. MAIN PWB CIRCUIT	20
15. MAIN/DISPLAY PWB LAYOUTS	21
16. KEYBOARD LAYOUTS	22
17. PARTS GUIDE	23

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-1875 service manual.html](https://the-checkout-tech.com/manuals/sharp/ER-1875%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)