

# SHARP SERVICE MANUAL

CODE: 00ZER1875SM-E

## ELECTRONIC CASH REGISTER

PRINTER: CR-802 2-10

SERVICE KEY CODE: LKGIM6861RCZZ



## MODEL **ER-1875**

### CONTENTS

1. INTERNAL BLOCK DIAGRAM .....	1
2. REFERENCE DOCUMENT .....	2
3. OPTIONS .....	2
4. SPECIFICATIONS .....	2
5. OUTLINE OF FUNCTIONS .....	7
6. SERVICE (SRV) MODE .....	8
7. PROGRAM (PGM) MODE .....	11
8. DATE MODE .....	12
9. READING (X) & RESETTING (Z) MODE .....	13
10. SERVICE PRECAUTIONS .....	14
11. CIRCUIT BLOCK DIAGRAM .....	15
12. CIRCUIT DESCRIPTIONS .....	16
13. LI3078 TERMINAL SIGNAL .....	19
14. MAIN PWB CIRCUIT .....	20
15. MAIN/DISPLAY PWB LAYOUTS .....	21
16. KEYBOARD LAYOUTS .....	22
17. PARTS GUIDE .....	23

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)