


SHARP SERVICE MANUAL

CDDE: 00ZER1970SM-E



ELECTRIC CASH REGISTER

MODEL ER-1970

SRV KEY : LKGIM7113RCZZ
PRINTER : CR-802A

CONTENTS

CHAPTER 1. SPECIFICATION	1
CHAPTER 2. OPTIONS	3
CHAPTER 3. HARDWARE DESCRIPTION	4
CHAPTER 4. TEST FUNCTION	11
CHAPTER 5. CIRCUIT DIAGRAM & PWB LAYOUT	13
PARTS GUIDE	

Parts marked with "△" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-1970 service manual.html](https://the-checkout-tech.com/manuals/sharp/ER-1970%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)