


SHARP PROGRAMMING MANUAL

CODE: 00ZER1970PM-E



ELECTRONIC CASH REGISTER

MODEL ER-1970

SRV KEY : LKGIM7113RCZZ

CONTENTS

| | |
|---|----|
| CHAPTER 1. SERVICE (SRV) MODE | 1 |
| CHAPTER 2. PROGRAM MODE | 6 |
| CHAPTER 3. OP X/Z, X1, Z1/Z2, Z2 MODE | 13 |

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)