

SHARP

SERVICE MANUAL

CODE: 00ZER2370SM-E

ELECTRONIC CASH REGISTER

PRINTER: CR-812

SERVICE KEY CODE: LKGIM6861RCZZ



MODEL **ER-2370**

CONTENTS

1. INTERNAL BLOCK DIAGRAM	1
2. REFERENCE DOCUMENT	2
3. OPTIONS	2
4. SPECIFICATIONS	3
5. OUTLINE OF FUNCTIONS	8
6. SERVICE (SRV) MODE	9
7. PROGRAM (PGM) MODE	15
8. DATE MODE	19
9. READING (X) & RESETTING (Z) MODE	20
10. TEST FUNCTIONS (IN SERVICE 1 MODE)	23
11. SERVICE PRECAUTIONS	27
12. CIRCUIT BLOCK DIAGRAM	28
13. CIRCUIT DESCRIPTIONS	29
14. μ PD7801G AND μ PD7507C TERMINAL SIGNAL	34
15. INSTALLATION OF ER-18DT	35
16. INSTALLATION OF ER-47RA	36
17. MAIN CIRCUIT	37
18. MAIN PWB LAYOUT	38
19. DISPLAY & KEYBOARD CIRCUIT	39
20. DISPLAY PWB LAYOUT	40
21. KEYBOARD PWB LAYOUT	41
22. PARTS GUIDE & PARTS LIST	42

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-2370 service manual.html](https://the-checkout-tech.com/manuals/sharp/ER-2370%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)