

# SHARP

# SERVICE MANUAL

CODE: 00ZER2371SM-E



## ELECTRONIC CASH REGISTER

PRINTER: CR-812, CR-911A (for Australia)  
SERVICE KEY CODE: LKGIM6861RCZZ

## MODEL **ER-2371**

### CONTENTS

1. INTERNAL BLOCK DIAGRAM .....	1
2. REFERENCE DOCUMENT .....	2
3. OPTIONS .....	2
4. SPECIFICATIONS .....	3
5. OUTLINE OF FUNCTIONS .....	8
6. SERVICE (SRV) MODE .....	9
7. PROGRAM (PGM) MODE .....	15
8. DATE MODE .....	18
9. READING & RESETTING (X & Z) MODE .....	19
10. TEST FUNCTIONS (IN THE SERVICE 1 MODE) .....	22
11. SERVICE PRECAUTIONS .....	25
12. CIRCUIT BLOCK DIAGRAM .....	26
13. CIRCUIT DESCRIPTIONS .....	26
14. $\mu$ PD7801G AND $\mu$ PD7507C TERMINAL SIGNAL .....	31
15. MAIN PWB CIRCUIT DIAGRAM .....	34
16. MAIN PWB LAYOUT .....	35
17. DISPLAY & KEYBOARD CIRCUIT .....	36
18. DISPLAY PWB LAYOUT .....	37
19. KEYBOARD PWB LAYOUT .....	38
20. PARTS GUIDE & PARTS LIST .....	39

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-2371 service manual.html](https://the-checkout-tech.com/manuals/sharp/ER-2371%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)