

SHARP SERVICE MANUAL



ELECTRONIC CASH REGISTER

PRINTER:

CR-340A (ER-2722/2742)
CR-341A (ER-2782)

ER-2782



ER-2722



ER-2742

SHARP CORPORATION

CONTENTS

	Page		Page
1. INTERNAL BLOCK DIAGRAM	2	5. PGM MODE	26
2. REFERENCE DOCUMENTS	3	5-1. Preset	26
3. SPECIFICATIONS	3	5-2. Preset Reading	27
3-1. Destinations	3	6. DATE MODE	27
3-2. Model Comparison	3	7. X, Z MODE	28
3-3. Rating	3	7-1. Reading (X mode)	28
3-4. Outline of Functions	4	7-2. Resetting (Z mode)	28
3-5. Key layout	6	8. OPTIONS	28
3-6. Display	8	9. PRECAUTIONS ON SERVICING	29
3-7. Printer	9	10. CIRCUIT BLOCK DIAGRAM	30
3-8. Print Format	11	11. CIRCUIT DESCRIPTIONS	31
3-9. Drawer/Lock	16	11-1. Basic Clock Pulse	31
3-10. Error Processing	16	11-2. POFF Circuit	31
3-11. Power Failure Processing	16	11-3. RESET (RES) circuit	32
3-12. Validation Printing	16	11-4. ROM, RAM Control	33
3-13. Memories (RAM)	17	11-5. Key, Mode Switch Receipt on/off Switch Scanning	34
4. SRV MODE	18	11-6. Display Control	37
4-1. Program Reset	18	11-7. Printer Control	39
4-2. Master Reset	18	11-8. Clock Control	44
4-3. Preset	18	11-9. Power Supply Circuit	45
4-4. Preset Reading	24	11-10. VRES Circuit	45
4-5. Display, Printer Test	25	12. CIRCUIT DIAGRAM & P.W.B. LAYOUT	
4-6. Printer Test	25	13. PARTS GUIDE	

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)