

SHARP

SERVICE MANUAL



ER-2722A ER-2742A MODEL ER-2782A

ELECTRONIC CASH REGISTER

ER-2782A

PRINTER

- CR-340A (ER-2722A/2742A)
- CR-341A (ER-2782A)

MODE KEY NO.

- SRV Key 9B5
- MA Key 6B2
- SM Key 0B9
- OP Key 0B6

CONTENTS

	Page		Page
1. INTERNAL BLOCK DIAGRAM	1	5-1. Programming	20
2. REFERENCE DOCUMENTS	2	5-2. Reading of Programming	21
3. SPECIFICATIONS	2	6. DATE MODE	22
3-1. Destinations	2	7. X,Z MODE	22
3-2. Model Comparison	3	7-1. Reading (X mode)	22
3-3. Rating	4	7-2. Resetting (Z mode)	22
3-4. Outline of Functions	4	8. OPTIONS	23
3-5. Key layout	4	9. PRECAUTIONS ON SERVICING	24
3-6. Display	7	10. CIRCUIT BLOCK DIAGRAM	25
3-7. Printer	8	11. TERMINAL SIGNALS OF μ PD7802G-011	26
3-8. Print Format	10	12. CIRCUIT DESCRIPTIONS	27
3-9. Drawer/Lock	10	12-1. Basic Clock Pulse	27
3-10. Error Processing	10	12-2. P OFF Circuit	28
3-11. Power Failure Processing	10	12-3. RESET Circuit	29
3-12. Validation Printing	10	12-4. ROM, RAM Control	30
3-13. Memories (RAM)	10	12-5. Key & Switch Scanning	30
4. SRV MODE	10	12-6. Display Control	32
4-1. Program Reset	10	12-7. Printer Control	33
4-2. Master Reset	10	12-8. Drawer Control	36
4-3. Programming	11	12-9. Power Supply Circuit	37
4-4. Reading of Programming	18	12-10. VRES Circuit	38
4-5. Display, Printer Test	19	12-11. Clock Control	38
4-6. Printer Test	19	13. CIRCUIT DIAGRAM & PWB LAYOUT	
5. PGM MODE	20	14. PARTS GUIDE	

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)