

SHARP SERVICE MANUAL

CODE: 00ZER291OPSM1

ER-2910 OPTION #1

ER-20IN RS232C INTERFACE ER-20RS

CONTROL ROM MODEL ER-29RM5

C	ONTENTS
ER-20IN & ER-29RM5	1-1
ER20RS & ER-29RM5	
PARTS GUIDE	





IN-LINE INTERFACE & CONTROL ROMS FOR ER-2910 SYSTEM

ER-20IN MODEL ER-29RM5

(Options for ER-2910)

	CONTENTS —
1.	ER-2910 IN-LINE SYSTEM CONFIGURATION
2.	HARDWARE REQUIREMENTS1-2
3.	FILE/DATA ALLOCATION IN THE ER-2910 (IN-LINE) SYSTEM
4.	PROGRAM DATA UPDATING
5.	SRV-MODE PROGRAMMINGS
6.	PGM2 MODE PROGRAMMINGS1-10
7.	COMMUNICATION FUNCTION OUTLINE
8.	OPERATIONS IN THE SRN SYSTEMS
9.	READING (X) AND RESETTING (Z) REPORTS
10.	SOFTWARE INSTALLATION PROCEDURE FOR ER-2910 IN-LINE SYSTEM
11.	TEST FUNCTIONS
12.	HARDWARE DESCRIPTION
13.	CIRCUIT DIAGRAM1-19
14.	PWB LAYOUT

^{*} For the installation procedure of ER-20IN and ER-29RM5, refer to ER-2910 Service Manual.

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/sharp/ER-2910 RS232 option board service man

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM