



SHARP SERVICE MANUAL

CODE: 00ZER291OPSM1

ER-2910 OPTION #1

IN-LINE INTERFACE

ER-20IN

RS232C INTERFACE

ER-20RS

CONTROL ROM

MODEL ER-29RM5

CONTENTS

ER-20IN & ER-29RM5	1-1
ER20RS & ER-29RM5	2-1
PARTS GUIDE	

**IN-LINE INTERFACE &
CONTROL ROMS
FOR ER-2910 SYSTEM**

**ER-20IN
MODEL ER-29RM5**

(Options for ER-2910)

CONTENTS

1. ER-2910 IN-LINE SYSTEM CONFIGURATION	1-2
2. HARDWARE REQUIREMENTS	1-2
3. FILE/DATA ALLOCATION IN THE ER-2910 (IN-LINE) SYSTEM	1-3
4. PROGRAM DATA UPDATING	1-5
5. SRV-MODE PROGRAMMINGS	1-7
6. PGM2 MODE PROGRAMMINGS	1-10
7. COMMUNICATION FUNCTION OUTLINE	1-11
8. OPERATIONS IN THE SRN SYSTEMS	1-11
9. READING (X) AND RESETTING (Z) REPORTS	1-12
10. SOFTWARE INSTALLATION PROCEDURE FOR ER-2910 IN-LINE SYSTEM	1-13
11. TEST FUNCTIONS	1-14
12. HARDWARE DESCRIPTION	1-16
13. CIRCUIT DIAGRAM	1-19
14. PWB LAYOUT	1-20

* For the installation procedure of ER-20IN and ER-29RM5, refer to ER-2910 Service Manual.

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)