

SHARP SERVICE MANUAL

CODE : 00ZER2970SM-E



ELECTRONIC CASH REGISTER

MODEL **ER-2970**

OPTIONS: ER-29DP1
 ER-29DT
 ER-29DW1
 DR-45PL4 (45PL6)
 ER-46SP1
 PRINTER: M-220F
 SRV KEY: LKGiM6959RCZZ (2B5)

Revolving Display is option.

CONTENTS

1. Internal block diagram	1
2. Special service tools	1
3. Reference documents	1
4. Specifications	1
5. Options (ER-29DP1/29DT/29DW1/45PL4/46SP1 and Service options)	7
6. SRV (Service) mode	12
7. PGM (Program) mode	26
8. CLOCK mode	33
9. Reading & resetting modes (X, X1/Z1, X2/Z2)	33
10. Outline of functions	35
11. Test function (In the SRV1 mode)	37
12. Circuit block diagram	43
13. μ PD7801G and μ PD7507C terminal signals	44
14. Circuit descriptions	45
15. Service precautions	56
16. Earth wires connection diagram	58
17. Circuit diagrams and board layouts (Including ER-46SP1 circuit diagram)	
18. Parts guide	

NOTE: If "DISABLE" is selected for OPERATION AT DRAWER OPEN (SRV mode JOB#903-D ②), all programming operations in the SRV and PGM modes are inhibited unless drawer is closed.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-2970 service manual.html](https://the-checkout-tech.com/manuals/sharp/ER-2970%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)