

SHARP SERVICE MANUAL

CODE: 00ZER2980VSME



ELECTRONIC CASH REGISTER

MODEL ER-2980


OPTIONS: ER-46SP1 ER-11KT2 IO-17KP1V
 ER-34DW7 ER-12KT2 ER-29RS2
 ER-46PL1 ER-22KT2 ER-29AS1
 ER-30BT ER-12HK2 ER-29AS2
 ER-38CC ER-11DK2 ER-15CL
 ER-38CV ER-51DK2


PRINTER: M-220AF
 SRV KEY: LKGIM6861RCZZ

CONTENTS

1. Internal block diagram	1
2. Special service tools	1
3. Reference documents	1
4. Specifications	1
5. Options	11
6. Quick reference to program job numbers affecting keys, functions and reports	15
7. SRV (Service) mode	15
8. PGM1, PGM2 (Program) modes	27
9. Outline of functions	36
10. Print skipping SRV/PGM2 mode programmings	39
11. Test function (in the SRV mode)	39
12. Circuit block diagram	46
13. UPD7801G descriptions	47
14. SM-551-23P descriptions	49
15. Circuit descriptions	51
16. Service precautions	61
17. Circuit diagram and PWB Layout	62
18. Parts guide	

Installation manual for ER-2980V OPTIONS

NOTE: 1) WHEN UNPAKING A MACHINE FOR THE USER, REMOVE ALUMINUM TAPE WHERE STICK ON THE CLERK KEY SWITCH.
 2) MASTER RESET (ALL MEMORIES CLEAR)
 THIS FUNCTION HAS BEEN CHANGED TO JOURNAL KEY (),
 NOT THE NUMERIC 9 KEY ([9])



This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-2980 service manual.html](https://the-checkout-tech.com/manuals/sharp/ER-2980%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)