

SHARP SERVICE MANUAL

CODE: 00ZER29RSSM-E

RS232C INTERFACE

NOTE: As installation procedure of the ER-29RS is described in this service manual (section 11), installation manual of the ER-29RS will not be issued separately.

MODEL ER-29RS

Option for ER-2970

CONTENTS

1.	General Descriptions	1
2.	Components	1
3.	Specifications of RS232C Interface	2
4.	Block Diagram	3
5.	Application Specifications of ER-2970	4
	5-1. Fundamental Specifications	4
	5-2. Interface with External Equipments	4
	5-3. Presets by Jumper-Switch	10
6.	Example of Connection	11
7.	Character Code Table	12
8.	Test Function	13
9.	Circuit Descriptions	16
10.	Installation Procedure of ER-29RS	19
11.	Circuit Diagram and PWB Layout	21
12.	Parts List	23

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)