

SHARP PARTS GUIDE

CODE:00ZER3100PG-E



ELECTRONIC CASH REGISTER

SECTION 3 . PARTS

MODEL ER-3100

SRV key : LKGiM7113RCZZ

PRINTER: M-2640

CONTENTS

- 1 Exteriors (cabinet, printer etc.)
 - 2 Keyboard unit
 - 3 Packing material & Accessories
 - 4 Drawer box unit (KA, KB)
 - 5 Drawer box unit (U.S.A., CANADA, TQ, TR, TS)
 - 6 Main PWB unit
 - 7 Display PWB unit
 - 8 RAM PWB unit
 - 9 Noise filter PWB unit (Except U.S.A., CANADA)
 - 10 Customer display PWB unit
 - 11 Articles of consumptions
 - 12 Service options
 - 13 AC Cord
- Index

Parts marked with "▲" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-3100 parts guide manual.html](https://the-checkout-tech.com/manuals/sharp/ER-3100%20parts%20guide%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)