




SHARP SERVICE MANUAL

CODE:00ZER3110VSME



ELECTRONIC CASH REGISTER

MODEL ER-3110

SRV Key : LKGIM7113RCZZ
PRINTER : M-2640

CAUTION
EXTREME CAUTION MUST BE TAKEN WHEN SERVICEING THIS MACHINE. EVEN THOUGH THE MODE SWITCH IS IN THE OFF POSITION, VOLTAGE IS STILL SUPPLIED TO THE ENTIRE MACHINE.
WHEN WORKING ON THIS MACHINE MAKE SURE THAT THE POWER CORD IS REMOVED FROM THE WALL OUTLET.

CONTENTS

	Page
1. Block Diagram	1
2. Special Service Tools	2
3. Reference Documents	3
4. Specifications	3
5. Options	7
6. Service Precations	9
7. Down load Function	10
8. Test Function	13
9. Circuit Description	27
10. Installation of Options	49
11. Circuit Diagram and PWB Layout	71
Parts Guide	

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-3110 service manual.html](https://the-checkout-tech.com/manuals/sharp/ER-3110%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)