

SHARP SERVICE MANUAL

CODE : 00ZER311VOSME

ER-3110 OPTION #1

IN-LINE INTERFACE

ER-30IN

RS232C INTERFACE

ER-30RS

CONTROL ROM

MODEL ER-31RM

CONTENTS

ER-30IN & ER-31RM	1-1
ER30RS & ER-31RM	2-1
PARTS GUIDE	

**IN-LINE INTERFACE &
CONTROL ROMS
FOR ER-3110 SYSTEM**

**ER-30IN
MODEL ER-31RM**

(Options for ER-3110)

CONTENTS

1. ER-3110 IN-LINE SYSTEM CONFIGURATION	1-2
2. HARDWARE REQUIREMENTS	1-2
3. FILE/DATA ALLOCATION IN THE ER-3110 (IN-LINE) SYSTEM	1-3
4. TEST FUNCTIONS	1-14
5. HARDWARE DESCRIPTION	1-16
6. CIRCUIT DIAGRAM	1-19
7. PWB LAYOUT	1-20

* For the installation procedure of ER-30IN and ER-31RM, refer to ER-3110 Service Manual.

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)