

# SHARP SERVICE MANUAL

CODE: 00ZER3120PSME

**ER-3120 OPTION**

**RAM BOARD**

**ER-01MB**

**IN-LINE INTERFACE**

**ER-30IN**

**RS232C INTERFACE**

**ER-30RS**

**CONTROL ROM**

**MODEL ER-31RM2**

CONTENTS

ER-30IN & ER-31RM2 .....	1-1
ER30RS & ER-31RM2 .....	2-1
ER-01MB PWB LAYOUT .....	3-2
PARTS GUIDE	

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)