

SHARP SERVICE MANUAL

CODE:00ZER3310SM-E



[ER-3310]

**ELECTRONIC
CASH REGISTER**

**ER-3310
MODEL ER-3311**

SRV Key :LKGIM7113RCZZ
PRINTER:M-2640

CAUTION
EXTREME CAUTION MUST BE TAKEN WHEN SERVICING THIS MACHINE. EVEN
THOUGH THE MODE SWITCH IS IN THE OFF POSITION, VOLTAGE IS STILL
SUPPLIED TO THE ENTIRE MACHINE.
WHEN WORKING ON THIS MACHINE MAKE SURE THAT THE POWER CORD IS
REMOVED FROM THE WALL OUTLET.

CONTENTS

1. Block Diagram	1
2. Special Service Tools	2
3. Reference Documents	3
4. Specifications	3
5. Options	12
6. SRV/PGM mode Program List	13
7. Service (SRV) mode	21
8. Program (PGM2/PGM1) mode	36
9. OP X/Z, X1, Z1/X2/Z2 mode	50
10. Service Precautions	51
11. Down load Function	55
12. Test Function	59
13. Circuit Description	69
14. Installation of Service Options	104
15. Circuit Diagram and PWB Layout	109
Parts Guide	

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/sharp/ER-3310> and [ER-3311](https://the-checkout-tech.com/manuals/sharp/ER-3311) service and progra

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)