


SHARP PARTS GUIDE

CODE: 00ZER4100PG-E



ER-4100



ER-4110

ER-4100 MODEL ER-4110

CONTENTS

1 Exteriors	11 ER-41PI Slip I/F PWB unit
2 ER-4100 Keyboard unit	12 ER-41MA/ER-41SL SRN I/F PWB unit
3 ER-4110 Keyboard unit	13 ER-41MA Packing material & Accessories
4 Packing material & Accessories	14 ER-41SL Packing material & Accessories
5 Drawer box unit (for KA, KB)	15 ER-33MB RAM PWB unit
6 MainPWB unit	16 ER-33MB Packing material & Accessories
7 Display PWB unit (Front display)	17 Optional parts
8 Customer display PWB unit	18 Articles for consumption
9 Power supply unit	19 AC cord
10 ER-41PI Exteriors	■ Index

Parts marked with "△" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/sharp/ER-4100> and [ER-4110 parts guide manual](https://the-checkout-tech.com/manuals/sharp/ER-4110)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)