

# SHARP SERVICE MANUAL

CODE:00ZER4100SMHE

## ELECTRONIC CASH REGISTER

### SECTION 2 HARDWARE

# ER-4100 MODEL ER-4110



ER-4100



ER-4110

SRV Key : LKGIM7113RCZZ

PRINTER: M-2662A

OPTIONS :

ER-41PI	(SLIP I/F Board)
ER-33MB	(Memory Board (32KB))
ER-01RA	(Memory chip (32KB))
ER-31MD1~5	(OPTIONAL Mode SW)
ER-37DW3	(OPTION Drawer)
ER-67LC	(LEVEL CONVERTER)
ER-01FD, ER-02FD	(3.5" FDD UNIT)
ER-52CB	(Loader cable)
ER-41MA	(INLINE MASTER)
ER-41SL	(INLINE SLAVE)
ER-01RP	(Kitchen printer)
ER-52SP	(SLIP PRINTER (M-545))

## CONTENTS

1. Block diagram	1
2. Special Service Tools	2
3. Reference Documents	3
4. Service precatations	3
5. Test Function	3
6. Description of main LSI's	18
7. Circuit description	28
8. ER-41PI (SLIP I/F Board)	51
9. ER-52SP (SLIP PRINTER)	52
10. ER-33MB, ER-01RA (Memory option)	55
11. ER-52CB (LOADER CABLE)	56
12. ER-67LC (LEVEL CONVERTER)	56
13. ER-37DW3 (REMOTE DRAWER)	58
14. ER-41MA, ER-41SL (INLINE option)	59
15. Circuit diagram and PWB Layout	75

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)