


# SHARP SERVICE MANUAL

CODE : 00ZER41RSSM-E



ER-4100

ER-4110

## RS-232C INTERFACE KIT

# MODEL ER-41RS

(OPTION FOR ER-4100 / 4110)

### CONTENTS

1. GENERAL DESCRIPTION .....	1
2. COMPONENTS .....	1
3. SPECIFICATIONS OF RS-232C INTERFACE .....	2
4. SYSTEM CONFIGURATIONS .....	3
5. SIGNAL CONNECTION DIAGRAM .....	6
6. TRANSMISSION PROTOCOL (FOR ER-4100/4110-PC) .....	7
7. CONTROL SIGNAL SEQUENCE .....	14
8. DATA FORMAT .....	18
9. APPLICATION SPECIFICATION .....	19
10. KITCHEN PRINTER SYSTEM .....	32
11. WIDE PRINTER SYSTEM .....	34
12. TEST FUNCTION .....	36
13. CIRCUIT DESCRIPTION .....	40
14. RS-232C WIRING CHARTS .....	47
15. NOTE ABOUT D-SUB CONNECTOR COVER .....	49
16. CIRCUIT DIAGRAM AND PWB LAYOUT .....	50
PARTS GUIDE	

SHARP CORPORATION

This document has been published to be used for after sales service only. The contents are subject to change without notice.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-41RS option service RS232 manual.ht](https://the-checkout-tech.com/manuals/sharp/ER-41RS_option_service_RS232_manual.ht)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)