SHARP SERVICE MANUAL

CODE: OOZER4230FSME



ELECTRONIC CASH REGISTER

MODEL ER-4230F

PRINTER: Model-220F(Z) SRV KEY: LKGIM6861RCZZ

(No Mode Key No.)

CAUTION

EXTREME CAUTION MUST BE TAKEN WHEN SERVICING THIS MACHINE. EVEN THOUGH THE MODE SWITCH IS IN THE OFF POSITION, VOLTAGE IS STILL SUPPLIED TO THE ENTIRE MACHINE. WHEN WORKING ON THIS MACHINE MAKE SURE THAT THE POWER CORD IS REMOVED FROM THE WALL OUTLET.

CONTENTS

1. Introduction 1
2. General 1
3. Reference documents 1
4. SRV mode setting 2
5. Test functions in the SRV mode 3
6. Circuit description 3
7. Printer M-220F(Z) 4
8. Circuit diagram and PWB layout 6
9. Part guide 9

SHARP CORPORATION

This is a "Table of Contents preview" for quality assurance

The full manual can be found at http://the-checkout-tech.com/estore/catalog/

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<u>http://the-checkout-tech.com</u> : the biggest supplier of cash register and scale manuals on the net