

# SHARP SERVICE MANUAL

CÔDE: OOZER4230FSME



## ELECTRONIC CASH REGISTER

### MODEL **ER-4230F**

PRINTER: Model-220F(Z)

SRV KEY: LKGIM6861RCZZ  
(No Mode Key No.)

#### CAUTION

EXTREME CAUTION MUST BE TAKEN WHEN SERVICING THIS MACHINE. EVEN THOUGH THE MODE SWITCH IS IN THE OFF POSITION, VOLTAGE IS STILL SUPPLIED TO THE ENTIRE MACHINE. WHEN WORKING ON THIS MACHINE MAKE SURE THAT THE POWER CORD IS REMOVED FROM THE WALL OUTLET.

#### CONTENTS

1. Introduction -----	1
2. General -----	1
3. Reference documents -----	1
4. SRV mode setting -----	2
5. Test functions in the SRV mode -----	3
6. Circuit description -----	3
7. Printer M-220F(Z) -----	4
8. Circuit diagram and PWB layout -----	6
9. Part guide -----	9

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-4230F service differences manual.htm](https://the-checkout-tech.com/manuals/sharp/ER-4230F_service_differences_manual.htm)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)