

# SHARP®




ELECTRONIC CASH REGISTER  
ELEKTRONISCHE REGISTRIERKASSE  
CAISSE ENREGISTREUSE ELECTRONIQUE  
CAJA REGISTRADORA ELECTRONICA

MODEL  
MODELL  
MODELE  
MODELO

**ER-A160**  
**ER-A180**

INSTRUCTION MANUAL  
BEDIENUNGSANLEITUNG

MANUEL D'INSTRUCTIONS  
MANUAL DE INSTRUCCIONES



The above illustration shows model ER-A180.  
Die obenstehende Abbildung zeigt das Modell ER-A180.

L'illustration ci-dessus montre le modèle ER-A180.  
La ilustración anterior muestra el modelo ER-A180.

**CAUTION:**

The cash register should be securely fitted to the supporting platforms to avoid instability when the drawers are open.

**CAUTION:**

The socket-outlet shall be installed near the equipment and shall be easily accessible.

**VORSICHT:**

Die Netzsteckdose muß nahe dem Gerät angebracht und leicht zugänglich sein.

**ATTENTION:**

La prise de courant murale devra être installée à proximité de l'équipement et devra être facilement accessible.

**AVISO:**

El tomacorriente debe estar instalado cerca del equipo y debe quedar bien accesible.

**WARNING:**

Det matande vägguttaget skall placeras nära apparaten och vara lätt åtkomligt.

**CAUTION:**

For a complete electrical disconnection pull out the mains plug.

**VORSICHT:**

Zur vollständigen elektrischen Trennung vom Netz den Netzstecker ziehen.

**ATTENTION:**

Pour obtenir une mise hors-circuit totale, débrancher la prise de courant secteur.

**AVISO:**

Para una desconexión eléctrica completa, desenchufar el enchufe de tomacorriente.

**WARNING:**

För att helt koppla från strömmen, dra ut stickproppen.

This equipment complies with the requirements of Directives 89/336/EEC and 73/23/EEC as amended by 93/68/EEC.

Dieses Gerät entspricht den Anforderungen der EG-Richtlinien 89/336/EWG und 73/23/EWG mit Änderung 93/68/EWG.

Ce matériel répond aux exigences contenues dans les directives 89/336/CEE et 73/23/CEE modifiées par la directive 93/68/CEE.

Dit apparaat voldoet aan de eisen van de richtlijnen 89/336/EEG en 73/23/EEG, gewijzigd door 93/68/EEG.

Dette udstyr overholder kravene i direktiv nr. 89/336/EEC og 73/23/EEC med tillæg nr. 93/68/EEC.

Quest' apparecchio è conforme ai requisiti delle direttive 89/336/EEC e 73/23/EEC, come emendata dalla direttiva 93/68/EEC.

Η εγκατάσταση αυτή ανταποκρίνεται στις απαιτήσεις των οδηγιών της Ευρωπαϊκής Ένωσης 89/336/ΕΟΚ και 73/23/ΕΟΚ, όπως οι κανονισμοί αυτοί συμπληρώθηκαν από την οδηγία 93/68/ΕΟΚ.

Este equipamento obedece às exigências das directivas 89/336/CEE e 73/23/CEE, na sua versão corrigida pela directiva 93/68/CEE.

Este aparato satisface las exigencias de las Directivas 89/336/CEE y 73/23/CEE, modificadas por medio de la 93/68/CEE.

Denna utrustning uppfyller kraven enligt riktlinjerna 89/336/EEC och 73/23/EEC så som komplette ras av 93/68/EEC.

Dette produktet oppfyller betingelsene i direktivene 89/336/EEC og 73/23/EEC i endringen 93/68/EEC.

Tämä laite täyttää direktiivien 89/336/EEC ja 73/23/EEC vaatimukset, joita on muutettu direktiivillä 93/68/EEC.

---

# INTRODUCTION

Thank you very much for your purchase of the SHARP Electronic Cash Register, Model ER-A160/ER-A180. Please read this manual carefully before operating your machine in order to gain full understanding of functions and features.

Please keep this manual for future reference, it will help you, if you encounter any operational problems.

## CAUTION!

Never install the batteries into the cash register before initializing it. Before you start operating the cash register, you must first initialize it, then install the batteries. Otherwise, distorted memory contents and malfunction of the cash register will occur. For their procedures, please refer to page 6.

---

# IMPORTANT

- **Install your register in a location that is not subject to direct radiation, unusual temperature changes, high humidity or exposed to water sources.**  
Installation in such locations could cause damage to the cabinet and the electronic components.
- **Never operate the register with wet hands.**  
The water could seep into the interior of the register and cause component failure.
- **When cleaning your register, use a dry, soft cloth. Never use solvents, such as benzine and/or thinner.**  
The use of such chemicals will lead to discoloration or deterioration of the cabinet.
- **The register plugs into any standard wall outlet (Official (nominal) voltage).**  
Other electrical devices on the same electrical circuit could cause the register to malfunction.
- **If the register malfunctions, call your local dealer for service - do not try to repair the register yourself.**
- **For a complete electrical disconnection, pull out the mains plug.**

---

# CONTENTS

<b>INTRODUCTION</b> .....	<b>1</b>
<b>IMPORTANT</b> .....	<b>1</b>
<b>CONTENTS</b> .....	<b>2</b>
<b>PARTS AND THEIR FUNCTIONS</b> .....	<b>3</b>
<b>GETTING STARTED</b> .....	<b>6</b>
<b>BASIC SALES ENTRY</b> .....	<b>10</b>
<b>OTHER TYPES OF ENTRIES</b> .....	<b>12</b>
1 Item entries .....	12
Single item entries .....	12
Repeat entries .....	12
Multiplication entries .....	13
Single item cash sale (SICS) entry .....	13
2 Displaying subtotals .....	14
3 Finalization of transaction .....	14
Cheque or credit sale .....	14
4 Computation of VAT/tax .....	14
VAT/tax system .....	14
5 Auxiliary entries .....	15
Percent calculations (premium or discount) .....	15
Discount entries .....	16
Refund entries .....	16
Printing of non-add code numbers .....	16
6 Payment treatment .....	17
Currency exchange .....	17
Received on account entries .....	18
Paid out entries .....	18
No sale (exchange) .....	18
7 Receipt issuance after finalization .....	18
8 Automatic sequence key (AUTO key) entries .....	18
9 Override entries .....	19
<b>CORRECTION</b> .....	<b>19</b>
<b>READING (X) AND RESETTING (Z) OF SALES TOTALS</b> .....	<b>21</b>
1 Summary of reading (X) and resetting (Z) reports .....	21
2 Sample reports .....	22
<b>PROGRAMMING</b> .....	<b>24</b>
1 Programming the VAT/tax rate .....	24
2 Programming for departments .....	24
3 PLU(Price Lookup) programming .....	26
4 Programming for miscellaneous keys .....	27
5 Programming various functions .....	29
6 Reading stored program .....	33
<b>PROGRAMMING FOR EURO</b> .....	<b>34</b>
<b>OPERATOR MAINTENANCE</b> .....	<b>37</b>
1 Replacing the batteries .....	37
2 Replacing the paper roll .....	38
3 Replacing the ink ribbon .....	39
4 Ink refill (ER-A180 only) .....	40
5 Drawer handling .....	41
6 Opening the drawing by hand .....	42
7 Installing the fixing angle bracket .....	42
8 In case of power failure or paper jam .....	43
9 Program resetting .....	43
10 Before calling for service .....	43
<b>LIST OF OPTIONS</b> .....	<b>44</b>
<b>SPECIFICATIONS</b> .....	<b>44</b>

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/sharp/ER-A160> and [ER-A180](https://the-checkout-tech.com/manuals/sharp/ER-A180) instruction manual

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)