

SHARP PARTS GUIDE

MODEL ER-A250

PRINTER: CR-750
(for KA, KB, TQ, TS)

CONTENTS

- | | |
|----------------------------------|----------------------------|
| 1 Exteriors | 6 Pop-up display PWB unit |
| 2 Keyboard unit | 7 Articles for consumption |
| 3 Packing material & Accessories | 8 Service route options |
| 4 Drawer box unit (SK423 type) | 9 AC cord |
| 5 Main PWB unit | ■ Index |

The IC numbers (IC1, IC2,.....) on the circuit diagrams and the Parts Guide are expressed as U1, U2,.....on the PWB silk.

Because parts marked with "△" is indispensable for the machine safety maintenance and operation, it must be replaced with the parts specific to the product specification.

Table of destinations

| SELECTION CODE | COUNTRIES |
|----------------|--|
| U | U. S. A., Guam |
| A | Canada |
| TS | Germany |
| TQ | SEEG territory other than Germany (Stamp : English) |
| TR | SEEG territory other than Germany (Stamp : Spanish) |
| KB | U. Kingdom |
| KA | Australia |

| SELECTION CODE | COUNTRIES |
|----------------|-----------|
| K | Korea |

| SELECTION CODE | COUNTRIES |
|----------------|---|
| SB | Saudi Arabia (127V area) |
| SBA | Saudi Arabia (220V area) |
| SC | Taiwan |
| SD | Venezuela |
| SE | Hong Kong |
| SG | Lebanon, Syria, Greece, Pakistan, Iran, Egypt, Thailand, Iraq, Mauritius, Seychelles, Tahiti, Jordan, Sudan, Turkey |
| SH | South Africa (U. S. A. version) |
| SHE | South Africa (Europe version) |
| SJ | Philippines (Europe version) |
| SJ2 | Philippines (U. S. A. version) |
| SM | Kuwait, Qatar, Oman, UAE, Malta, Bahrain |
| SMT | Nigeria, Yemen, Kenya |

| SELECTION CODE | COUNTRIES |
|----------------|---|
| RA1 | Morocco, Algeria, Tunisia, West Africa |
| RA2 | Chile, Uruguay, Peru, Argentina, Paraguay |
| RA5 | Sri Lanka |

| SELECTION CODE | COUNTRIES |
|----------------|-----------------------------|
| RB3 | Indonesia |
| RB4 | |
| RB5 | Cyprus |
| RB6 | Panama |
| RB7 | Barbados |
| RB8 | Malaysia (U. S. A. version) |

| SELECTION CODE | COUNTRIES |
|----------------|-----------------------------|
| RC1 | Malaysia (Europe version) |
| RC2 | Singapore |
| RC5 | Dominican Republic, Ecuador |

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)