
SHARP INSTALLATION MANUAL

CODE: 00ZERA310VIME



ELECTRONIC CASH REGISTER

ER-A310MODEL **ER-A330**

SRV Key: LKGIM7113RCZZ PRINTER: ER-A310: CR-510

ER-A330: UCR-812A

(For "V" version)

CONTENTS

CHAPTER	1.	GENERAL
CHAPTER	2.	LIST OF OPTIONS
CHAPTER	3.	REMOVING THE TOP CABINET (For ER-A310 & ER-A330) 2
CHAPTER	4.	REMOVING THE BOTTOM CABINET (Only for ER-A330)
CHAPTER	5.	REMOVING THE PRINTER UNIT (For ER-A310 & ER-A330) 4
CHAPTER	6.	REMOVING THE MAIN PWB (For ER-A310 & ER-A330) 4
CHAPTER	7.	REMOTE DRAWER: ER-04DW (For ER-A310 & ER-A330) 5
CHAPTER	8.	DRAWER FIXING KIT: DKIT-8670RCZZ (Only for ER-A330) 6
CHAPTER	9.	SHIELD PLATE KIT: DKIT-8666BHZZ (Only for ER-A330) 7
CHAPTER 1	0.	ONE HOLE CASHIER KEY KIT: DKIT-8669BHZZ
		(For ER-A310 & ER-A330)
CHAPTER 1	1.	KEY TOP KIT: ER-11KT7/12KT7/22KT7/11DK7/51DK7
		(For ER-A310 & ER-A330)

Parts marked with "! " is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/sharp/ER-A310 and ER-A330 installation manual

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM