

SHARP PROGRAMMING MANUAL

CODE : 00ZERA320UPME

ELECTRONIC CASH REGISTER



(For "U" & "V" version) SRV KEY: LKGIM7113RCZZ PRINTER: UCR-812AII

| CONTENTS | |
|-------------------------------------|--|
| | |
| | |
| CHAPTER 1. SERVICE (SRV) MODE1 | |
| | |
| CHAPTER 2. PROGRAM (PGM) MODE9 | |
| CHAPTER 3. OP X/Z X1/Z1, X2/Z2 MODE | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

Parts marked with "<u>A</u>" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

SHARP CORPORATION

This document has been published to be used for after sales service only. The contents are subject to change without notice. Click here to download the full manual at THE-CHECKOUT-TECH.COM