

# SHARP PARTS GUIDE

CODE: 00ZUCR812APGD

## PRINTER

## MODEL UCR-812A

### CONTENTS

- Parts Guide
  - KI-OB6783RCZZ
  - KI-OB6784RCZZ

For operational description, disassembly, re-assembly, and machine maintenance procedures, please refer to the CR-802/812 Service Manual.

CR-802/812 Service manual: 00ZCR812SM/-E

APPLICATION MODEL (As of Sep./1996)

KI-OB6783RCZZ: ER-A330 ("U" & "A" Version)

KI-OB6784RCZZ: ER-A330 ("V" Version)

Because parts marked with "△" is indispensable for the machine safety maintenance and operation, it must be replaced with the parts specific to the product specification.

SHARP CORPORATION

This document has been published to be used for after sales service only. The contents are subject to change without notice.

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)