
SHARP PROGRAMMING MANUAL

CODE: 00ZERA410UP2E



ELECTRONIC CASH REGISTER

ER-A410 MODEL ER-A420

(For "U/A" version) SRV KEY: LKGIM7113RCZZ

CO	NΙΤ	NΙΤ	27
\mathcal{L}	ועו	IV I	

CHAPTER 1.	SERVICE (SRV) MODE
CHAPTER 2.	PROGRAM (PGM2/PGM1) MODE2 - 1
CHAPTER 3.	OP X/Z, X1/Z1, X2/Z2 MODE

Parts marked with "_\(\tilde{\Lambda}\)" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/sharp/ER-A410 and ER-A420 program U and A

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM