
## SHARP PROGRAMMING MANUAL

CODE: 00ZERA410VPME



## **ELECTRONIC CASH REGISTER**

## ER-A410 MODEL ER-A420

(For "V" version) SRV KEY:LKGIM7113RCZZ PRINTER:PR-45M II

CO	NIП	NΙΤ	re
	IV I	IV I	

CHAPTER 1.	SERVICE (SRV) MODE
CHAPTER 2.	PROGRAM (PGM2/PGM1) MODE2 - 1
CHAPTER 3.	OP X/Z, X1/Z1,X2/Z2 MODE
CHAPTER 4.	CHANGING EURO FUNCTION (X2/Z2 MODE JOB) 4 - 1

Parts marked with "\_\(\!\!^\)" are important for maintaining the safety of the set. be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/sharp/ER-A410 and ER-A420 programming man

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM