

SHARP®

ELECTRONIC CASH REGISTER

MODEL

ER-A410
ER-A420

INSTRUCTION MANUAL



The above illustration shows the model ER-A410.

CAUTION:

The cash register and the remote drawer should be securely fitted to the supporting platforms to avoid instability when the drawers are open.

CAUTION:

The socket-outlet shall be installed near the equipment and shall be easily accessible.

VORSICHT:

Die Netzsteckdose muß nahe dem Gerät angebracht und leicht zugänglich sein.

ATTENTION:

La prise de courant murale devra être installée à proximité de l'équipement et devra être facilement accessible.

AVISO:

El tomacorriente debe estar instalado cerca del equipo y debe quedar bien accesible.

WARNING:

Det matande vägguttaget skall placeras nära apparaten och vara lätt åtkomligt.

CAUTION:

For a complete electrical disconnection pull out the mains plug.

VORSICHT:

Zur vollständigen elektrischen Trennung vom Netz den Netzstecker ziehen.

ATTENTION:

Pour obtenir une mise hors-circuit totale, débrancher la prise de courant secteur.

AVISO:

Para una desconexión eléctrica completa, desenchufar el enchufe de tomacorriente.

WARNING:

För att helt koppla från strömmen, dra ut stickproppen.

This equipment complies with the requirements of Directives 89/336/EEC and 73/23/EEC as amended by 93/68/EEC.

Dieses Gerät entspricht den Anforderungen der EG-Richtlinien 89/336/EWG und 73/23/EWG mit Änderung 93/68/EWG.

Ce matériel répond aux exigences contenues dans les directives 89/336/CEE et 73/23/CEE modifiées par la directive 93/68/CEE.

Dit apparaat voldoet aan de eisen van de richtlijnen 89/336/EEG en 73/23/EEG, gewijzigd door 93/68/EEG.

Dette udstyr overholder kravene i direktiv nr. 89/336/EEC og 73/23/EEC med tillæg nr. 93/68/EEC.

Quest' apparecchio è conforme ai requisiti delle direttive 89/336/EEC e 73/23/EEC, come emendata dalla direttiva 93/68/EEC.

Η εγκατάσταση αυτή ανταποκρίνεται στις απαιτήσεις των οδηγιών της Ευρωπαϊκής Ένωσης 89/336/ΕΟΚ και 73/23/ΕΟΚ, όπως οι κανονισμοί αυτοί συμπληρώθηκαν από την οδηγία 93/68/ΕΟΚ.

Este equipamento obedece às exigências das directivas 89/336/CEE e 73/23/CEE, na sua versão corrigida pela directiva 93/68/CEE.

Este aparato satisface las exigencias de las Directivas 89/336/CEE y 73/23/CEE, modificadas por medio de la 93/68/CEE.

Denna utrustning uppfyller kraven enligt riktlinjerna 89/336/EEC och 73/23/EEC så som komplette ras av 93/68/EEC.

Dette produktet oppfyller betingelsene i direktivene 89/336/EEC og 73/23/EEC i endringen 93/68/EEC.

Tämä laite täyttää direktiivien 89/336/EEC ja 73/23/EEC vaatimukset, joita on muutettu direktiivillä 93/68/EEC.



INTRODUCTION

Thank you very much for your purchase of the SHARP Electronic Cash Register, Model ER-A410/A420. Please read this manual carefully before operating your machine in order to gain full understanding of functions and features.

Please keep this manual for future reference. It will help you, if you encounter any operational problems.

IMPORTANT

- **Install your register in a location that is not subject to direct sunlight, unusual temperature changes, high humidity or exposure to water sources and keep away from heat and magnetic sources.**
Installation in such locations could cause damage to the cabinet and the electronic components.
- **The register should not be operated by an individual with wet hands.**
The water could seep into the interior of the register and cause component failure.
- **When cleaning your register, use a dry, soft cloth. Never use solvents, such as benzine and/or thinner.**
The use of such chemicals will lead to discoloration or deterioration of the cabinet.
- **The register plugs into any standard wall outlet (Official (nominal) voltage).**
Other electrical devices on the same electrical circuit could cause the register to malfunction.
- **If the register malfunctions, call your local dealer for service - do not try to repair the register yourself.**
- **For a complete electrical disconnection, pull out the mains plug.**

PRECAUTION

This Electronic Cash Register has a built-in memory protection circuit which is operated by rechargeable batteries.

As you know, all batteries will, in time, dissipate their charge even if not used. Therefore to insure an adequate initial charge in the protection circuit, and to prevent any possible loss of memory upon installation, it is recommended that each unit be allowed to recharge for a period of 24 to 48 hours prior to use by the customer. In order to charge the batteries, the machine must be plugged in. This recharging precaution can prevent unnecessary initial service calls.



CONTENTS

INTRODUCTION	1
IMPORTANT	1
PRECAUTION	1
CONTENTS	2
EXTERNAL VIEW OF THE ER-A410	7
Front view	7
Rear view	7
EXTERNAL VIEW OF THE ER-A420	8
Front view	8
Rear view	8
PRINTER	9
KEYBOARD	10
1 ER-A410 standard keyboard layout	10
2 ER-A420 standard keyboard layout	12
3 Standard key number layout	13
4 Inserting of the key sheet (ER-A420)	14
KEYS AND SWITCHES	15
1 Mode switch and mode keys	15
2 Drawer lock key	15
DISPLAYS	16
1 Operator display	16
2 Customer display (Pop-up type)	16

FOR THE MANAGER

PRIOR TO PROGRAMMING	17
1 Programming keyboard layout	17
2 How to program alphanumeric characters	18
Using character keys on the keyboard	18
Entering character codes	18
PROGRAMMING	20
Basic instructions	20
Preparations for programming	20
Direct Programming	20
1 Setting the date and time	20
Date	20
Time	21
2 Programming for departments	21
Unit price	21
Functional selection	22
3 Price lookup (PLU) programming	23
Unit price	23
Functional selection	24
PLU assignment to department	25
4 Programming for discount keys (⊖)	26
Deduction amount	26
5 Programming for percent and exchange keys (⊘ and EX)	26
Percent rate and currency exchange rate	26
6 Programming for discount and percent keys (⊖ and %)	27



High amount lockout (HALO), item/subtotal selection, and +/- sign	27
7 Programming for exchange keys (EX)	28
Tab of foreign currency	28
8 Programming for the RA and PO keys	28
High amount lockout (HALO)	28
9 Programming for the CH, CR, CA2, and TL keys	29
High amount lockout (HALO) and functional selection	29
10 Programming the tax rate	30
Tax rate	30
Job-Code-Based Programming	31
1 Setting the date and time	31
Setting the date (#2610)	31
Setting the time (#2611)	31
2 Setting the register and consecutive numbers	32
Setting the register number (#2612)	32
Setting the consecutive number (#2613)	32
3 Programming the tax rate	33
Tax rate (#2711)	33
4 Programming for departments	34
Functional programming (#2110)	34
Tax status (#2111)	35
A limit amount (HALO) of entry (#2112)	36
Alphanumeric characters (#2114)	36
Unit price (#1110)	37
Commission group assignment (#2115)	37
Group number (#2116)	38
Department key positioning (#2119)	39
5 Price lookup (PLU) programming	40
Department assignment (#1200, 2230)	41
Unit prices (#1210)	42
Base quantity (#1211)	42
PLU/subdepartment mode (#2210, 2231)	43
Sign (+/-) and tax status (#2211, 2232)	44
Alphanumeric characters (#2214)	45
Assigning of PLUs to commission groups (#2215, 2235)	46
Stock quantity (#1222, 1220, 1221)	47
Set PLU (#2221)	48
Link PLU (#2220)	49
Mix-and-match table (#2250, 2251, 2254)	49
Programming of PLU levels and direct PLU keys (#2219)	51
6 Programming for miscellaneous keys	52
Programming the rate (% , EX, commission) and the deduction (⊖) (#1310)	52
Programming the tab of foreign currency (EX) (#2330)	53
Currency description text programming (EX) (#2334)	53
Assigning the drawer number to the drawer for foreign currency (#2680)	54
A limit amount (HALO) of entry (⊖, DEPO (+), DEPO (-), RA, PO) (#2312)	54
+/- sign (% , ⊖) (#2311)	55
Item % or subtotal % selection (%) (#2315)	56
Percent rate limitation (%) (#2313)	56
Item ⊖ or subtotal ⊖ selection (⊖) (#2316)	57
7 Programming for the TL, CA2, CH through CH4, and CR1 through CR4 keys	58
Functional programming (#2320)	58
High amount lockout (HALO) for cheque cashing, cheque change and cash in drawer (#2321)	60
High amount lockout (HALO) of entry for media keys (#2322)	60



8	Programming of function text	61
	Programming (#2314)	61
	List of function texts	62
9	Cashier and clerk programming	64
	Cashier code (#1500)	64
	Cashier name (#1514)	64
	Functional programming for cashiers (#2510)	65
	Programming of PBLU code (#2511)	65
	Clerk code (#1400)	66
	Clerk name (#1414)	66
10	Programming various functions	67
	Programming for optional feature selection (#2616)	67
	Programming alarm length of time with drawer opening (#2617)	72
	Programming of validation printing, slip printing, and difference subtotal printing (#2615)	72
	Programming of logo messages (#2614)	73
	Programming of error messages (#2641)	74
	Programming of texts of validation printing (#2642)	75
	Programming of texts of slip printing (#2643)	75
	Programming of payee name (for English cheque) (#2646)	76
	Selection of X1/Z1 and X2/Z2 reports to be printed in the stacked report sequence (#2620)	77
	Setting the time range for hourly reports (#2619)	78
	Programming of power saving mode (#2689)	78
	Functional programming for the printer (#2990)	79
	Programming for EURO change job (#2681, 2682, 2683)	79
	RS-232C channel assignment (#2690)	81
	Programming of RS-232C interface (#6110, 6111, 6112, 6113, 6115, 6220)	82
	Secret codes to control access to the PGM1 mode, X1/Z1 mode and X2/Z2 mode (#2630, 2631, 2632)	83
	Setting the AUTO key – Automatic sequencing key – (#2900)	84
11	Training mode	85
12	Reading stored programs	86
	Program details and procedures for their reading	86
	Sample printouts	88
	READING (X) AND RESETTING (Z) OF SALES TOTALS	95
1	Summary of reading (X) and resetting (Z) reports and the key operations to obtain the reports	95
2	Daily sales totals	98
	General report	98
	Cashier report	102
	Clerk report	104
	Hourly report	105
	Full department report	106
	Individual group total report on department	107
	Full group total report on department	107
	PLU/subdepartment report by designated range	108
	PLU/subdepartment report by associated department	109
	PLU/subdepartment zero sales report	109
	PLU/subdepartment price category report	109
	PLU/subdepartment stock report	110
	PBLU report	110
	PBLU report by cashier	111
	Balance report	111
	Commission sales report	112
	Transaction report	112
	Total in drawer report	112



X1/Z1 stacked report	112
3 Periodic consolidation	113
Generality	113
Daily net report	114
X2/Z2 stacked report	114
COMPULSORY CASH/CHEQUE DECLARATION	115
PROGRAMMING FOR EURO	117
Automatic modification of register system for introduction of EURO	118
Optional programming for the introduction of EURO	119
OVERRIDE ENTRIES	120
CORRECTION AFTER FINALIZING A TRANSACTION (AFTER GENERATING A RECEIPT)	121

FOR THE OPERATOR

PRIOR TO ENTRIES	122
1 Preparations for entries	122
Receipt and journal paper rolls	122
Receipt ON/OFF function	122
Cashier and clerk assignment	122
Power saving mode	123
2 Error warning	123
ENTRIES	124
1 Item entries	124
Single item entries	124
Repeat entries	125
Multiplication entries	126
Successive multiplication entries	127
Split-pricing entries	128
Single item cash sale (SICS)/single item finalize (SIF) entries	129
2 Special entries for PLUs	130
PLU level shift (for direct PLU)	130
Price level shift	132
Set PLU entries	133
Link PLU entries	134
Mix-and-match function	135
3 Displaying and printing subtotals	136
Normal subtotal	136
Difference subtotal (Differ ST)	136
4 Finalization of transaction	137
Cash or cheque tendering	137
Mixed tendering (cheque + cash)	137
Cash or cheque sale that does not need any tender entry	138
Credit sale	138
Mixed-tender sale (cash or cheque tendering + credit tendering)	138
5 Computation of VAT (Value Added Tax)/tax	139
VAT/tax system	139
VAT shift entries	140
6 Guest check (PBLU)	141
PBLU system	141
Deposit entries	143
Bill printing	144
7 Auxiliary entries	145
Percent calculations (premium or discount)	145
Deduction entries	145



Refund entries	146
Printing of non-add code numbers	146
8 Payment treatment	147
Currency exchange	147
Received on account entries	148
Paid out entries	148
No sale (exchange)	149
Cashing a cheque	149
9 Automatic sequencing key (AUTO key) entries	149
CORRECTION	150
1 Correction of the last entry (direct void)	150
2 Correction of the next-to-last or earlier entries (indirect void)	150
3 Subtotal void	151
4 Correction of incorrect entries not handled by the direct or indirect void function	151
SPECIAL PRINTING FUNCTIONS	152
1 Copy receipt printing	152
2 Guest check copy	153
3 Printing of header and footer graphic logos	153
4 Validation printing function	154
5 Printing of the employee's arrival and departure times	154
6 French EURO cheque printing	154
7 English cheque printing	154
OVERLAPPED CASHIER ENTRY	155
OPERATOR MAINTENANCE	156
1 In case of power failure	156
2 In case of printer error	156
3 Thermal printing	156
Cautions in handling the printer	156
Cautions in handling the recording paper (thermal paper)	157
4 Installing and removing the paper roll	158
Recording paper specifications	158
Installing the paper roll	158
Removing the paper roll	160
Removing a paper jam	161
5 Cleaning the print head	162
6 Removing the till and the drawer	163
7 Opening the drawer by hand	163
8 Installing the fixing angle bracket	164
9 Before calling for service	165
Error message table	165
LIST OF OPTIONS	166
SPECIFICATIONS	167



[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)