

3 MAY 1

ER-A430VP

SHARP PROGRAMMING MANUAL

CODE: 00ZERA430VPME



ELECTRONIC CASH REGISTER

MODEL ER-A430

(For "V" version)

SRV KEY : LKGIM7113RCZZ

PRINTER : DP-630-S

CONTENTS

CHAPTER 1. SERVICE (SRV) MODE	1
CHAPTER 2. PROGRAM (PGM2/PGM1) MODE	8
CHAPTER 3. OP X/Z, X1/Z1, X2/Z2 MODE	19

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-A430 programming manual.html](https://the-checkout-tech.com/manuals/sharp/ER-A430%20programming%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)