

SHARP SERVICE MANUAL

CODE: 00ZERA430VSME



ELECTRONIC CASH REGISTER

MODEL ER-A430

SRV Key : LKGIM7113RCZZ
PRINTER: DP630-S
(For "V" version)

CONTENTS

CHAPTER 1. SPECIFICATIONS	1
CHAPTER 2. OPTIONS	5
CHAPTER 3. SRV. RESET AND MASTER RESET	6
CHAPTER 4. HARDWARE DESCRIPTION	7
CHAPTER 5. TEST FUNCTION	16
CHAPTER 6. DOWN LOAD FUNCTION	18
CHAPTER 7. CIRCUIT DIAGRAM & PWB LAYOUT	22

PARTS GUIDE

Parts marked with "△" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-A430 service manual.html](https://the-checkout-tech.com/manuals/sharp/ER-A430%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)