

SHARP®

ELECTRONIC CASH REGISTER

MODEL

ER-A430

INSTRUCTION MANUAL



If undue force is applied to the drawer, the cash register will become unstable.

CAUTION:

The socket-outlet shall be installed near the equipment and shall be easily accessible.

VORSICHT:

Die Netzsteckdose muß nahe dem Gerät angebracht und leicht zugänglich sein.

ATTENTION:

La prise de courant murale devra être installée à proximité de l'équipement et devra être facilement accessible.

AVISO:

El tomacorriente debe estar instalado cerca del equipo y debe quedar bien accesible.

VARNING:

Det matande vägguttaget skall placeras nära apparaten och vara lätt åtkomligt.

This apparatus complies with the requirements of BS 800 (EN 55014): 1988 and BS 6527 (EN 55022): 1988.

Dieses Gerät stimmt mit den Bedingungen der EN 55014, 02. 1987 und der EN 55022, 04. 1987 überein.

Cet appareil répond aux spécifications de la EN 55014, 02. 1987 et EN 55022, 04. 1987.

Dit apparaat voldoet aan de vereiste EN 55014, 02. 1987 en EN 55022, 04. 1987.

Apparatet opfylder kravene i EN 55014, 02. 1987 og EN 55022, 04. 1987.

Questo apparecchio è stato prodotto in conformità alle EN 55014, 02. 1987 e EN 55022, 04. 1987.

Αύτή ή συσκευή τηρεί τις προδιαγραφές της EN 55014, 02. 1987 και EN 55022, 04. 1987.

Este aparelho responde às especificações da EN 55014, 02. 1987 e EN 55022, 04. 1987.

Este aparato cumple las especificaciones de la EN 55014, 02. 1987 y EN 55022, 04. 1987.

CAUTION:

For a complete electrical disconnection pull out the mains plug.

VORSICHT:

Zur vollständigen elektrischen Trennung vom Netz, den Netzstecker ziehen.

ATTENTION:

Pour obtenir une mise hors-circuit totale, débrancher la prise de courant secteur.

AVISO:

Para una desconexión eléctrica completa, desenchufar el enchufe de tomacorriente.

VARNING:

För att helt koppla från strömmen, dra ut stickproppen.

INTRODUCTION

Thank you very much for your purchase of the SHARP Electronic Cash Register, Model ER-A430. Please read this Manual carefully before operating your machine in order to gain a full understanding of its functions and performance.

Please keep this Manual for future reference. It will help you, if you encounter any operational problems.

IMPORTANT

- **Install your ER-A430 in a location that is not subject to direct radiation, unusual temperature changes, high humidity or exposed to water sources.**
Installation in such locations could cause damage to the cabinet and the electrical components.
- **The register should not be operated by an individual with wet hands.**
The water could seep into the interior of the ER-A430 and cause component failure.
- **When cleaning your register, use a dry, soft cloth. Never use volatile liquid, such as benzine and thinner.**
The use of such chemicals will lead to discoloration or deterioration of the cabinet.
- **The ER-A430 register plugs into any standard wall outlet (Official (nominal) voltage).**
Other electrical devices on the same electrical circuit could cause the ER-A430 to malfunction.
- **If the register malfunctions, call your local dealer for service — Do not try to repair the register yourself.**

PRECAUTION

This Electronic Cash Register has a built-in memory protection circuit which is operated by rechargeable batteries.

As you know, all batteries will, in time, dissipate their charge even if not used.

Therefore to insure an adequate initial charge in the protection circuit, and to prevent any possible loss of memory upon installation, it is recommended that each unit be allowed to recharge for a period of 24 to 48 hours prior to use by the customer.

In order to charge the batteries, the machine must be plugged in and left on in the "REG" (Registration) mode. This recharging precaution can prevent unnecessary initial service calls.

CONTENTS

	Page
• PHYSICAL CHARACTERISTICS OF THE ER-A430 REGISTER	5
• KEYBOARD LAYOUT AND SWITCH AND KEY DESCRIPTIONS	7
1. Keyboard	7
2. Mode switch and mode keys	8
• DISPLAYS	10
1. Operator display	10
2. Customer display	11
• GENERAL INSTRUCTIONS	12
• PROGRAMMING	13
1. Setting the date and time	13
(1) Setting the date (#2610)	13
(2) Setting the time (#2611)	14
2. Setting the register number (#2612)	14
3. Setting the consecutive number (#2613)	15
4. Programming for departments	15
(1) Programming of unit prices (#1110)	15
(2) Functional programming (#2110)	16
(3) Programming of tax status (#2111)	17
(4) Setting a limit amount (HALO) of entry (#2112)	18
(5) Assigning departments to groups (#2116)	18
(6) Programming of department text (#2114)	19
ALPHANUMERIC CHARACTER CODE TABLE	20
5. Programming for PLUs	21
(1) Definition of PLU codes and department assignment (#1200)	22
(2) Programming of unit prices (#1210)	22
(3) Programming of base quantity (#1211)	23
(4) Programming of sign and tax status (#2211)	24
(5) Programming of PLU text (#2214)	25
6. Function parameter programming	26
(1) Programming of premium and discount rates and currency exchange rate (#1310)	26
(2) Programming of tax rate (#2711)	26
(3) Function programming for the finalization keys (#2320)	27
(4) Programming of sign (for %, ⊖) (#2311)	28
(5) Item % or subtotal % selection (#2315)	28
(6) Item ⊖ or subtotal ⊖ selection (#2316)	29
(7) Programming of HALO for percent calculation (#2313)	29
(8) Programming of HALO for deduction, received on account, and paid out (#2312)	30
(9) Programming of HALO for the finalization keys (#2322)	30
(10) Programming of HALO for cash in drawer, cheque change, and cheque cashing (#2321)	31
(11) Programming of function text (#2314)	32
LIST OF FUNCTION TEXTS	33
7. Cashier programming	36
(1) Cashier code definition (#1500)	36
(2) Programming of the cashier name (#1514)	36

(3) Programming drawer numbers for cashiers (#2510)	37
8. Programming alarm length of time with drawer opening (#2617)	37
9. Programming for optional feature selection (#2616)	38
10. Programming the number of times of validation printing (#2615)	40
11. Logo text programming (#2614)	41
12. Selection of X1/Z1 and X2/Z2 reports to be printed in the stacked report sequence (#2620)	43
13. Reading stored programs	44
(1) Program details and procedures for their reading	44
(2) Sample printouts	45
• REGISTRATIONS	49
* Preparations for entries	49
* Error warning	49
1. Cashier assignment	49
2. Item entries	50
(1) Single item entries	50
(2) Repeat entries	51
(3) Multiplication entries	52
(4) Split-pricing entries	53
(5) Single item cash sale (SICS)/single item finalize (SIF) entries	54
3. Display of subtotals	54
4. Finalization of transaction	55
(1) Cash or cheque tendering	55
(2) Mixed tendering (cheque + cash)	55
(3) Cash or cheque sale that does not need a tender amount entry	56
(4) Credit sale	56
(5) Mixed-tender sale (cash or cheque tendering + credit sale)	56
5. Computation of VAT (Value Added Tax)/tax	57
6. Auxiliary entries	58
(1) Percent calculations (premium or discount)	58
(2) Deduction	59
(3) Refund entries	59
(4) Printing of non-add code numbers	60
7. Payment treatment	60
(1) Currency exchange	60
(2) Received on account entries	61
(3) Paid out entries	61
(4) No sale (exchange)	62
(5) Cashing a cheque	62
• CORRECTION	63
1. Correction of the last entry (direct void)	63
2. Correction of the next-to-last or earlier entries (indirect void)	63
3. Correction of the subtotal (subtotal void)	64
4. Handling of errors found after receipt issuance	64
• SELECTION OF RECEIPT ISSUANCE	65
• VARIOUS PRINTING	65
1. Copy receipt printing	65
2. Validation printing function	66

2-1. Validation slip setting and printing	66
2-2. The validation printing can occur just after the following registrations	67
(1) Validation printing of item entries	67
(2) Validation printing after the finalization of a transaction	68
2-3. Validation slip specification	68
• OVERLAPPED CASHIER ENTRY	69
• PRINTING OF THE EMPLOYEE ARRIVAL AND DEPARTURE TIMES	70
• MANAGER MODE	70
• CORRECTION AFTER FINALIZING A TRANSACTION (AFTER GENERATING A RECEIPT)	71
• TIME DISPLAY AND AUTOMATIC UPDATING OF THE DATE	72
• AUTOMATIC KEY FUNCTION	73
• READING (X) AND RESETTING (Z) OF SALES TOTALS	74
— SAMPLE REPORTS —	76
• COMPULSORY CASH/CHEQUE DECLARATION	86
• TRAINING MODE	88
• OPERATOR MAINTENANCE	89
1. In case of power failure	89
2. In case of printer's motor locking	89
3. Paper roll near-end sensing function (only for journal paper) < option >	90
4. Installing and removing the paper roll	90
5. Installing the ink ribbon cassette	93
6. Ink refill	94
7. Removing the till and the drawer	95
8. Opening the drawer by hand	95
9. Before calling for service	96
— Program resetting —	96
• LIST OF OPTIONS	97
• SPECIFICATIONS	98

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)