

SHARP SERVICE MANUAL

CODE: 00ZERA43VOSME

ER-A430 OPTION

RS-232 INTERFACE

ER-A4RS

CONTROL ROM

MODEL **ER-A43R1**

(For "V" version)

CONTENTS

I.	RS-232 SYSTEM FOR ER-A430	1-1
II.	TEST FUNCTION FOR ER-A4RS	2-1
III.	HARDWARE DESCRIPTION FOR ER-A4RS	3-1
	PARTS GUIDE	

Parts marked with "△" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

I. RS-232 SYSTEM FOR ER-A430

ER-A4RS **MODEL ER-A43R1** **(OPTION FOR ER-A430)**

CONTENTS

CHAPTER 1. GENERAL	1-2
CHAPTER 2. COMPONENTS	1-2
CHAPTER 3. SPECIFICATIONS OF RS-232 INTERFACE	1-2
CHAPTER 4. BLOCK DIAGRAM AND SYSTEM CONFIGURATION	1-2
CHAPTER 5. SIGNAL CONNECTION DIAGRAM	1-3
CHAPTER 6. RS-232 PROTOCOL	1-5
CHAPTER 7. CONTROL SIGNAL SEQUENCE	1-12
CHAPTER 8. DATA BLOCK FORMAT	1-16
CHAPTER 9. RS-232 APPLICATION	1-19
CHAPTER 10. MESSAGE DISPLAY AND PRINT	1-31

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)