

SHARP PROGRAMMING MANUAL

CODE: 00ZERA440UPME



ELECTRONIC CASH REGISTER

MODEL ER-A440

(For "U" & "A" version)

SRV KEY : LKGIM7113RCZZ

PRINTER : DP-730

CONTENTS

CHAPTER 1. SERVICE (SRV) MODE	1
CHAPTER 2. PROGRAM (PGM2/PGM1) MODE	15
CHAPTER 3. OP X/Z, X1/Z1, X2/Z2 MODE	36

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-A440 programming U and A ver manu](https://the-checkout-tech.com/manuals/sharp/ER-A440%20programming%20U%20and%20A%20ver%20manua)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)