

SHARP PROGRAMMING MANUAL

CODE: 00ZERA440SVPM



ER-A440S



ER-A450S

ELECTRONIC CASH REGISTER

ER-A440S MODEL ER-A450S

(For "V" version)

SRV KEY: LKGIM7113RCZZ

PRINTER: DP-730 (Dot printer) for ER-A440S

PR-45M (Thermal printer) for ER-A450S

CONTENTS

CHAPTER 1. SERVICE (SRV) MODE	1-1
CHAPTER 2. PROGRAM (PGM2/PGM1) MODE	2-1
CHAPTER 3. OP X/Z, X1/Z1, X2/Z2 MODE	3-1
CHAPTER 4. CHANGING EURO FUNCTION (X2/Z2 mode JOB)...	4-1

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-A440S and ER-A450S programming m](https://the-checkout-tech.com/manuals/sharp/ER-A440S%20and%20ER-A450S%20programming%20manual.pdf)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)