

SHARP**SERVICE MANUAL**

CODE: 00ZERA450SVSM



ELECTRONIC CASH REGISTER

MODEL ER-A450S

SRV Key : LKGIM7113RCZZ

PRINTER: PR-45M

("V" version)

CAUTION

EXTREME CAUTION MUST BE TAKEN WHEN SERVICING THIS MACHINE. EVEN THOUGH THE MODE SWITCH IS IN THE OFF POSITION, VOLTAGE IS STILL SUPPLIED TO THE ENTIRE MACHINE.

WHEN WORKING ON THIS MACHINE MAKE SURE THAT THE POWER CORD IS REMOVED FROM THE WALL OUTLET.

CONTENTS

CHAPTER 1. SPECIFICATIONS	1-1
CHAPTER 2. OPTIONS	2-1
CHAPTER 3. SERVICE (SRV) MODE	3-1
CHAPTER 4. HARDWARE DESCRIPTION	4-1
CHAPTER 5. TEST FUNCTION	5-1
CHAPTER 6. DOWN LOAD FUNCTION	6-1
CHAPTER 7. SERVICE PRECAUTION	7-1
CHAPTER 8. CIRCUIT DIAGRAM & PWB LAYOUT	8-1

PARTS GUIDE

Parts marked with "△" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

SHARP CORPORATION

This document has been published to be used for after sales service only.
The contents are subject to change without notice.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-A450S service manual.html](https://the-checkout-tech.com/manuals/sharp/ER-A450S%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)