



SHARP SERVICE MANUAL

CODE: 00ZERA460VSME



ER-A460



ER-A470

ELECTRONIC CASH REGISTER

ER-A460 MODEL ER-A470

SRV Key : LKGIM7113RCZZ

PRINTER: DP-730

(For "V" version)

CAUTION

EXTREME CAUTION MUST BE TAKEN WHEN SERVICING THIS MACHINE. EVEN THOUGH THE MODE SWITCH IS IN THE OFF POSITION, VOLTAGE IS STILL SUPPLIED TO THE ENTIRE MACHINE.

WHEN WORKING ON THIS MACHINE MAKE SURE THAT THE POWER CORD IS REMOVED FROM THE WALL OUTLET.

CONTENTS

CHAPTER 1. SPECIFICATIONS	1
CHAPTER 2. OPTIONS	6
CHAPTER 3. SRV. RESET AND MASTER RESET	9
CHAPTER 4. HARDWARE DESCRIPTION	10
CHAPTER 5. TEST FUNCTION	32
CHAPTER 6. DOWN LOAD FUNCTION	39
CHAPTER 7. CIRCUIT DIAGRAM & PWB LAYOUT	41

PARTS GUIDE

Parts marked with "!" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

SHARP CORPORATION

This document has been published to be used for after sales service only.
The contents are subject to change without notice.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-A460 and ER-A470 service manual.htm](https://the-checkout-tech.com/manuals/sharp/ER-A460%20and%20ER-A470%20service%20manual.htm)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)