


CODE: 00ZERA460APME



ER-A460



ER-A470

ELECTRONIC CASH REGISTER

ER-A460 MODEL ER-A470

(For "A" version)

SRV KEY : LKGIM7113RCZZ

PRINTER : DP-730

CONTENTS

CHAPTER 1. SERVICE (SRV) MODE	1
CHAPTER 2. PROGRAM (PGM2/PGM1) MODE	13
CHAPTER 3. OP X/Z, X1/Z1, X2/Z2 MODE	38

The ER-A460/A470 has the Easy Programming function which allows the user to program easily.

This function is not described in this manual.

Please refer to the ER-A460/A470 EASY PROGRAMMING INSTRUCTION MANUAL of an accessory for the product.

This manual's parts code is a "TINSE7335BHZA".

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-A460 and ER-A470 programming A ve](https://the-checkout-tech.com/manuals/sharp/ER-A460%20and%20ER-A470%20programming%20A%20ve)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)